

ZxR100xC/ZMR100xR
E230 Residential Electricity Meter
User Manual



Date: 14.01.2015

Filename: D000044352 E230 ZxR100xC and ZMR100xR User Manual en g.docx

Revision history

Version	Date	Comments
a	30.06.2012	<p>Combined User Manuals D000028872 E230 ZxR100xC (version e, issue 1.32) and D000030166 E230 ZMR100xR (version e, issue 1.32).</p> <p>Section 2.4.7 <i>Temperature values</i>: Corrected maximum storage temperature (+70°C).</p> <p>Section 4.1.1 <i>Meter construction</i>: Added extra extended terminal cover.</p> <p>Section 6.6.1 <i>Tariff control (ZMR100xR only)</i>: Deleted Status signal.</p> <p>Section 6.9.1 <i>Manual setting of date/time/ID</i>: Added Id2.1 and Id2.2.</p> <p>Section 6.15 <i>IEC formatted commands</i>: Updated command list.</p> <p>Figure 13. <i>Drilling diagram for fixing screws</i>: Added 180 mm short fixing.</p> <p>Changed company name from “Landis+Gyr (Europe AG) to “Landis+Gyr AG”.</p> <p>Other minor formatting and wording changes.</p>
b	30.6.2012	Minor formatting changes.
c	25.07.2012	Corrected pulse output standard (IEC 62053-31).
d	17.08.2012	Section 2.4.10 <i>Output values</i> : Deleted “no measurement of load curve” from the description of pulse output r53.
e	11.02.2013	<p>Section 1 <i>About this document</i>: second restriction added.</p> <p>Section 2.1 <i>Functional overview</i>: measuring technology updated and RS485 interface added.</p> <p>Section 2.3.2 <i>E230 ZMR1x0AR/CR</i>: RS485 interface added.</p> <p>Section 2.4.6 <i>Power consumption</i>: power consumption data corrected.</p> <p>Section 2.4.10 <i>Output values</i>: RS485 interface added.</p> <p>Section 3.1 <i>Safety information</i>: safety concept updated and all notes, cautions and warnings reformatted.</p> <p>Section 4.2.5 <i>Multi-tariff version with one pulse input, one relay output and RS485 interface</i>: new diagram added.</p> <p>Section 4.2.6 <i>Multi-tariff version with four pulse inputs and RS485 interface</i>: new diagram added.</p> <p>Section 6.1 <i>Customer display</i>: figures redrawn and rate indication triangles added to list.</p> <p>Section 6.1.1 <i>Display cycle options</i>: previous billing added.</p> <p>Section 6.1.2 <i>Example displays</i>: RST replaced by L1, L2 and L3.</p> <p>OBIS codes for summation, DC field, terminal tamper and meter case tamper added.</p> <p>Section 6.1.4 <i>Meter powered with zero energy being consumed (anti-creep mode)</i>: expanded information about energy direction and phase indicators.</p> <p>Section 6.1.6 <i>Rate registers</i>: advanced Rate and Relay indication mode added.</p> <p>Section 6.3 <i>Push button operation</i>: using the MD button to reset alarms added.</p> <p>Section 6.4.6 <i>Alert notification</i>: alert notification lists added.</p> <p>Section 6.5 <i>No power read (optional fitting)</i>: inductive loop deleted.</p> <p>Section 6.7.4 <i>Reset of maximum demand</i>: MD register reset procedure updated.</p> <p>Section 6.8 <i>Billing (stored values) (ZMR100xR only)</i>: new section added.</p> <p>Section 6.8.1 <i>Unit suppression</i>: new section added.</p>

		<p>Section 6.9 <i>MDTP (Manual Date Time Programming) (ZMR100xR only)</i>: MDTP information updated.</p> <p>Section 6.9.1 <i>Manual setting of date/time/ID</i>: figures redrawn and reprogramming date and counts added.</p> <p>Section 6.13 <i>Communication interfaces</i>: RS485 interface added.</p> <p>Section 6.14.2 <i>Last configuration change identifier</i>: last configuration change identifier added.</p> <p>Section 6.15 <i>IEC formatted commands</i>: IEC formatted commands updated.</p> <p>Section 7.2.1 <i>Measurement Times</i>: new section added.</p>
f	02.08.2013	<p>Release 2 updates:</p> <p>New photographs.</p> <p>Disclaimer updated.</p> <p>Section 2.4.2 <i>RTC (Real Time Clock) accuracy (ZMR100xR only)</i> updated.</p> <p>Section <i>Starting values</i> deleted.</p> <p>Section 2.4.6 <i>Power consumption</i> updated.</p> <p>Section 2.5 <i>Data readout</i> updated.</p> <p>Section 4.1.1 <i>Meter construction</i> updated.</p> <p>Section 4.1.5 <i>Field of application</i> updated.</p> <p>Section 5.6.1 <i>Installation mode</i> updated.</p> <p>Section 6.1 <i>Customer display</i> updated.</p> <p>Section 6.1.1 <i>Display cycle options</i> updated.</p> <p>Section 6.1.2 <i>Example displays</i> updated.</p> <p>Section 6.1.3 <i>Energy efficiency meter displays (ZMR100xC only)</i> updated.</p> <p>Section <i>Import and export energy (ZMR100xC only)</i> deleted.</p> <p>Section <i>1-day and 7-day consumption registers (ZMR100xC only)</i> deleted.</p> <p>Section 6.1.6 <i>Rate registers</i> updated.</p> <p>Section 6.3 <i>Push button operation</i> updated.</p> <p>Section 6.4.1 <i>Reverse energy detection (RED)</i> updated.</p> <p>Section 6.4.2 <i>Tamper event log (ZMR100xR only)</i> updated.</p> <p>Section 6.4.5 <i>DC magnetic field intrusion</i> updated.</p> <p>Section 6.4.6 <i>Alert notification</i> updated.</p> <p>Section 6.6 <i>ToU (Time-of-Use) tables (ZMR100xR only)</i> updated.</p> <p>Section 6.6.1 <i>Tariff control (ZMR100xR only)</i> updated.</p> <p>Section 6.6.2 <i>Load control (ZMR100xR only)</i> updated.</p> <p>Section 6.7 <i>Maximum demand</i> updated.</p> <p>Section 6.7.4 <i>Reset of maximum demand</i> updated.</p> <p>Section 6.8 <i>Billing (stored values) (ZMR100xR only)</i> updated.</p> <p>Section 6.9.1 <i>Manual setting of date/time/ID</i> updated.</p> <p>Section 6.11.1 <i>Relay control (ZMR100xR only)</i> updated.</p> <p>Section 6.13 <i>Communication interfaces</i> updated.</p> <p>Section 6.15 <i>IEC formatted commands</i> updated.</p>
g	14.01.2015	<p>Section 6.4.2 <i>Tamper event log (ZMR100xR only)</i> updated.</p> <p>Section 8 <i>Error handling</i> added.</p>

Although the information contained within this document are presented in good faith and believed to be correct, Landis+Gyr (including its affiliates, agents and employees) disclaim any and all liability for any errors, inaccuracies or incompleteness relating to the product. Landis+Gyr makes no warranty, representation or guarantee regarding the performance, quality, durability or suitability of the products for any particular purpose. To the fullest extent permitted by law Landis+Gyr disclaims (1) any and all liability arising out of the use of the product, (2) any and all liability, including, but without limitation to, special, consequential and indirect damages and losses, and (3) any and all implied warranties, including, but without limitation to, fitness for purpose and merchantability.

The information contained in this document is strictly confidential and is intended for the addressee only. The unauthorised use, disclosure, copying, alteration or distribution of this document or the contents thereof is strictly prohibited and may be unlawful. All product information are subject to change without notice.

Table of contents

1	About this document	7
2	Introduction	9
2.1	Functional overview	9
2.2	Intended use and installation	9
2.3	Type designation	11
2.3.1	E230 ZxR1x0AC/CC	11
2.3.2	E230 ZMR1x0AR/CR	12
2.4	Technical details	13
2.4.1	Measuring accuracy	13
2.4.2	RTC (Real Time Clock) accuracy (ZMR100xR only)	13
2.4.3	Voltage values	13
2.4.4	Current values	13
2.4.5	Frequency values	14
2.4.6	Power consumption	14
2.4.7	Temperature values	14
2.4.8	External influences	14
2.4.9	Voltage interruption and restoration	15
2.4.10	Output values	15
2.4.11	Control inputs	17
2.5	Data readout	17
3	Safety	19
3.1	Safety information	19
3.2	Responsibilities	19
3.3	Safety regulations	20
4	Mechanical description	21
4.1	Meter description	21
4.1.1	Meter construction	23
4.1.2	Weight and dimensions	23
4.1.3	Faceplate details	24
4.1.4	Purpose of use	25
4.1.5	Field of application	25
4.2	External connection diagrams (ECD)	26
4.2.1	Single-tariff version	26
4.2.2	Single-tariff version with twin pulse outputs	26
4.2.3	Multi-tariff version with pulse input, pulse output and CS interface	27
4.2.4	Multi-tariff version with two pulse inputs, two pulse outputs and CS interface	27
4.2.5	Multi-tariff version with one pulse input, one relay output and RS485 interface	28
4.2.6	Multi-tariff version with four pulse inputs and RS485 interface	28
5	Installation and commissioning	29
5.1	Introduction	29
5.2	Materials and tools required	29
5.3	Mounting the meter	30
5.4	Connecting the meter	31
5.5	Final checks before applying power	32

5.6	Commissioning and functional check	32
5.6.1	Installation mode	33
6	Operation	34
6.1	Customer display	34
6.1.1	Display cycle options	34
6.1.2	Example displays	35
6.1.3	Energy efficiency meter displays (ZMR100xC only).....	38
6.1.4	Meter powered with zero energy being consumed (anti-creep mode)	38
6.1.5	Total registers.....	41
6.1.6	Rate registers	42
6.1.7	Instantaneous values	43
6.1.8	Maximum demand displays	45
6.1.9	Alert / report and test displays	46
6.2	Energy registers	47
6.3	Push button operation	48
6.4	Tamper detection.....	49
6.4.1	Reverse energy detection (RED)	49
6.4.2	Tamper event log (ZMR100xR only)	49
6.4.3	Meter cover opening (optional fitting)	52
6.4.4	Terminal cover opening (optional fitting)	52
6.4.5	DC magnetic field intrusion	52
6.4.6	Alert notification.....	52
6.5	No power read (optional fitting)	53
6.6	ToU (Time-of-Use) tables (ZMR100xR only).....	53
6.6.1	Tariff control (ZMR100xR only)	55
6.6.2	Load control (ZMR100xR only)	56
6.7	Maximum demand	56
6.7.1	'Slab' maximum demand	56
6.7.2	'Rolling' maximum demand	57
6.7.3	Maximum demand at power fail	57
6.7.4	Reset of maximum demand	57
6.8	Billing (stored values) (ZMR100xR only).....	58
6.8.1	Unit suppression.....	59
6.9	MDTP (Manual Date Time Programming) (ZMR100xR only).....	60
6.9.1	Manual setting of date/time/ID.....	60
6.10	Front panel optical port.....	63
6.11	Relays (ZMR100xR only)	63
6.11.1	Relay control (ZMR100xR only)	63
6.12	Energy measurement modes	63
6.12.1	Vectorial sum.....	63
6.12.2	Complete four-quadrant system	64
6.12.3	v1- or always positive registration, absolute value (SUM [ALi]).....	64
6.12.4	Import and export values.....	65
6.12.5	Energy consumption plus green energy generation.....	65
6.13	Communication interfaces	66
6.14	Security system	67
6.14.1	Access level 3 (ZMR100xR only)	68

6.14.2	Last configuration change identifier.....	68
6.15	IEC formatted commands.....	68
7	Maintenance.....	70
7.1	Meter check.....	70
7.2	Meter testing.....	70
7.2.1	Measurement Times.....	70
7.2.2	Post-installation configuration changes.....	71
7.3	Operating faults.....	71
7.4	Disconnecting the meter.....	72
7.5	Repairing the meter.....	72
8	Error handling.....	73
8.1	Error codes.....	73
8.2	Formatted commands and error codes.....	78
9	Decommissioning and disposal.....	79
10	Terms and abbreviations.....	80
10.1	Acronyms.....	80
10.2	Units.....	81
10.3	Standards.....	82

1 About this document

Range of validity

This user manual applies to the E230 ZxR100xC and ZMR100xR polyphase residential electricity meters.

The meter conforms to standards:

- IEC 62052-11
- IEC 62053-21
- IEC 62053-23
- IEC 62053-31
- EN 50470-1
- EN 50470-3

Purpose



Restriction for meters with software version up to and including v21.x.x (ZxR100xC) and v51.x.x (ZMR100xR):

The meters may not be used in networks with significant disturbances in the frequency range of 2 kHz to 150 kHz since the intended operating conditions of the meters according to the harmonised standards EN50470-1 and EN50470-3 assume no significant noise currents and voltages in this frequency range. Such significant disturbances occur, for instance, in large photovoltaic systems (influence of the inverters with high emissions of extreme harmonics) and can cause additional errors in the meters, even though the meters meet all applicable standards and directions.



Restriction for meters with software version up to and including K75 (ZxR100xC) and K52 (ZMR100xR):

Follow the measurement times for meter constant and dial tests specified in section 7.2.1. When switching a load (< 0.5 A to > 1A) on and off at regular intervals of about 20 minutes, an additional error of about 0.1% can occur. The deviation may be higher, if the load is switched on and off more often. The meter meets all specifications and applicable standards and regulations.

Contained in the user manual is all information required for the application of the meter for the intended purpose. This includes:

- Characteristics and functionality of the meter.
- Information about possible dangers, their consequences and measures to prevent them.
- A detailed description of the tasks to be performed during the entire life-cycle of the meter (configuration, installation, commissioning, operation, maintenance and disposal).

Target group

The contents of this user manual are intended for technically qualified personnel of energy supply companies responsible for system planning, installation and commissioning, operation, maintenance, decommissioning and disposal of the meter.

Reference documents

This document is available in the following languages:

Language	Document number
English	D000044352
German	D000044354

The following documents provide more information related to the subject of this document:

- D000028923 E230 ZxR100xC Technical Data en
- D000030167 E230 ZMR100xR Technical Data en
- D000042744 E230 Functional Description en

Typographical conventions

The following typographical conventions are used in this document:

Font	Description
<code>Courier</code>	Font for file names, paths and code examples.
Bold	Font style used for menu items and buttons in the user interface and for keyboard keys.
<i>Italics</i>	Font style for new terminology and references to other documents or other parts of this document. For example: “For more information on safety issues, see section 3 <i>Safety</i> .”

Terms and abbreviations

A list of terms and abbreviations used in this document is available at the end of this document.

2 Introduction

2.1 Functional overview

The meters have the following basic characteristics:

- Recording of active/reactive energy in one or more tariffs
- External tariff control via control input terminals
- Display of data with a liquid crystal display (LCD)
- Landis+Gyr's proprietary application-specific integrated circuit (ASIC) measurement technology using one shunt measuring element per phase
- Compliance with accuracy classes 1 and 2 according to IEC
- Compliance with accuracy classes A and B according to MID
- Flexible measuring system through the definition of different variables by software (single parameterisation by manufacturer)
- Correct measurement even with the failure of individual phases or when used in two- or single-phase networks
- Wide range of measurement from starting current to maximum current
- Serial interface with optical input/output
 - For direct readout of meter data
 - For communication with an extension
- CS and RS485 interface for remote communication of data
- Pulse output for transmission of constant pulses
- Relay output for switching external circuits (ZMR100xR only)
- Installation aids
 - Indication of the presence of phase voltages, rotating field and direction of energy
 - Power indicator
- Storage of additional information, such as operating times (readable via optical interface or, if present, the CS or RS485 interface).

2.2 Intended use and installation

The E230 ZxR100xC and E230 ZMR100xR meters record active and reactive energy consumption primarily in three-phase four-wire networks. The meter can operate on one phase (any phase and neutral), two phases (any two phases and neutral) and three phases with or without neutral. In addition, E230 ZxR100xC can also operate on three-phase delta configuration (F-Circuit). For this purpose, the meters are directly installed in the supply line by the energy supply company and are read regularly for energy charging purposes. They are used according to the technical specifications stated in the respective data sheets and in conjunction with this document.

The meter may solely be installed in a residential environment by qualified personnel. The meter conforms to IEC 62053, EN 50470 (MID) in its mechanical specification and is suitable for installation in any situation that also meets these standards. The meter must be installed away from powerful sources of electromagnetic interference.

There are no user serviceable parts within the meter and the meter must be returned to the manufacturer or an authorised partner for repair and/or maintenance. See sections 7 and 9. There are no permissible adjustments to meter installation procedure or meter operation outside those covered by the detailed operational instructions contained within this document

Any other application of these meters is not considered use for the intended purpose.

2.3 Type designation

2.3.1 E230 ZxR1x0AC/CC

The exact configuration of E230 products is expressed in a type code printed on the device face plate.

		ZMR	1	10	C	C	d	S1	f	CS
Network Type		_____								
ZMR	3-phase 4-wire network (M-circuit)									
ZFR	3-phase 3-wire network (F-circuit)									
Connection Type		_____								
1	Direct connection									
Accuracy Class		_____								
10	Active energy class 1 (IEC), B (MID)									
20	Active energy class 2 (IEC), A (MID)									
Measured Energy		_____								
A	Active energy									
C	Active and reactive energy									
Tariffication		_____								
C	No RTC									
Tariff Control Inputs		_____								
e	None (single rate)									
d	1 (two rates)									
t	2 (up to 4 rates)									
Pulse Outputs		_____								
-	None									
S1	1 pulse contact									
S2	2 pulse contacts									
Tampering Detection		_____								
-	None									
f	Yes									
Interfaces		_____								
-	None									
CS	CS									

In this user manual, the extensions found in the type designation for the tariff functions and pulse transmissions are not mentioned unless they provide a better understanding.

2.3.2 E230 ZMR1x0AR/CR

The exact configuration of E230 products is expressed in a type code printed on the device face plate.

	ZMR	1	10	A	R	d	S1	R1	s	f	CS
Network Type	_____										
ZMR	3-phase 4-wire network (M-circuit)										
Connection Type	_____										
1	Direct connection										
Accuracy Class	_____										
10	Active energy class 1 (IEC), B (MID)										
20	Active energy class 2 (IEC), A (MID)										
Measured Energy	_____										
A	Active energy										
C	Active and reactive energy										
Tariffication	_____										
R	Internal RTC										
Tariff Control Inputs	_____										
e	None (up to 6 rates)										
d	1 (up to 6 rates)										
t	2 (up to 6 rates)										
m	4 (up to 6 rates)										
Pulse Outputs	_____										
-	None										
S1	1 pulse contact										
S2	2 pulse contacts										
Relay Outputs	_____										
-	None										
R1	1 relay output										
R2	2 relay outputs										
Supercapacitor	_____										
-	None										
s	Supercapacitor										
Tampering Detection	_____										
-	None										
f	Yes										
Interfaces	_____										
-	None										
CS	CS										
RS	RS485										

In this user manual, the extensions found in the type designation for the tariff functions and pulse transmissions are not mentioned unless they provide a better understanding.

2.4 Technical details

2.4.1 Measuring accuracy

Active Energy	Class B or A MID/IEC class 1 or 2
Reactive Energy (Optional)	Class 2 or 3 IEC
Active Power (Instantaneous)	± 10%
Reactive Power (Instantaneous)	± 10%
VRMS (Instantaneous)	± 2%
IRMS (Instantaneous) at 0.25 A	± 2.5%
IRMS (Instantaneous) at 8.0 A	± 0.8%
IRMS (Instantaneous) at 100.0 A	± 1.0%
Frequency	± 2.0% at a resolution of 0.1 Hz
Power Factor	± 2.5%

2.4.2 RTC (Real Time Clock) accuracy (ZMR100xR only)

Crystal (internal to RTC)	32768 Hz ± 8 ppm max
Accuracy after calibration	± 3 ppm at 25°C
Temperature Drift	± 5 ppm / °C (-40°C...-15°C) ± 3 ppm / °C (-15°C...+60°C) ± 5 ppm / °C (+60°C...+70°C)

2.4.3 Voltage values

Rated Voltage (U_n)	
Nominal Value	3 x 230/400 V (3 x 120/200 V) 3 x 230 V
Operating Range	3 x 220/380 V to 3 x 240/415 V (3 x 110/190 V to 3 x 240/415 V)
Tolerance	0.8 to 1.15 U_n

2.4.4 Current values

MID Reference Current (I_{ref})	Configurable: 5, 10, 15 or 20 A
Maximum Current (I_{max})	125 A (Brass Terminals) 100 A (Steel Terminals)
Starting Current	
In accordance with MID Class B	0.4% I_{ref}
In accordance with MID Class A	0.5% I_{ref}
Maximum Measuring Range	Approx. 15 mA to 125 A
Load Capacity	
Measurements	125 A
Short Circuit < 10mS	10,000 A (standard 30 x I_{max})

2.4.5 Frequency values

Rated Supply Frequency	50 Hz \pm 5%, 60 Hz \pm 5%
-------------------------------	--------------------------------

2.4.6 Power consumption

In Voltage Path (ZxR1x0xR only)	U_n 110 V	U_n 230 V
Active at U _n (typ.)	1.0 W (per phase)	1.1 W (per phase)
Apparent at U _n (typ.)	1.0 VA (per phase)	1.1 VA (per phase)

In Voltage Path (ZxR1x0xC only)	U_n 110 V	U_n 230 V
Active at U _n (typ.)	0.6 W (per phase)	0.8 W (per phase)
Apparent at U _n (typ.)	0.6 VA (per phase)	0.8 VA (per phase)

In Current Path (ZxR1x0xC and ZxR1x0xR)	
Apparent at 5A (typ.)	0.015 VA (per phase)

2.4.7 Temperature values

Operating Temperature Range	-40°C to +70°C
Power Measurement Range	-40°C to +70°C
Storage Temperature Range	-40°C to +70°C
LCD Operating Temperature	From -25°C; will recover from temperatures below

2.4.8 External influences

Electromagnetic Compatibility	
Electrostatic Discharges	IEC 61000-4-2
Contact Discharge – Conductive Surfaces	8 kV
Air Gap Discharge – Non-Conductive Surfaces	15 kV
Electromagnetic High Frequency Fields	IEC 61000-4-3
80 MHz to 2 GHz	10 V/m & 30 V/m
Dwell Time	2 s
Line Transients (burst)	IEC 61000-4-4
Current and Voltage Circuits	4 kV
Auxiliary Circuits > 40V	2 kV
Rise Time	5 ns

Electromagnetic Compatibility	
Width	50 ns
Repetition Rate	5 kHz
Burst Duration	15 ms
Burst Period	300 ms
Surge Immunity	IEC 61000-4-5
Current and Voltage Circuits	4 kV
Auxiliary Circuits	1 kV
Rise Time	5 ns
Width	50 ns
Repetition Rate	5 kHz
Burst Duration	15 ms
Burst Period	300 ms
Radio Interference Suppression	IEC/CISPR 22 Class B

2.4.9 Voltage interruption and restoration

Voltage Interruption	
Blocking of Inputs and Outputs	Immediate
Standby Operation	Approx. 0.5 s
Data Storage	Immediate
Disconnection	Approx. 1 s

Voltage Restoration	
Ready for Service after	<5 s
Recognition of Energy Direction and Voltage after	<5 s

2.4.10 Output values

Display	
Type	Liquid Crystal Display (LCD), high performance Super-Twisted Nematic (STN) technology
Character Size (main digits)	10 mm

CS Interface	
Type	Serial bi-directional
Standard	IEC 61107 / DIN 66258
Rated Voltage	24V DC
Max. Voltage	30V DC
Transmitter Current – On state	Min. 11 mA Typ. 20 mA Max. 30 mA
Off State	Max. 2.5 mA
Receiver Current – On state	Min. 9 mA Typ. 20 mA Max. 30 mA
Off State	3 mA Max.
Communication Speed	300 to 4800 Baud

RS485 Interface (ZMR100xR only)	
Type	Half-duplex
Standard	ANSI TIA/EIA-485-A and ISO 8482:1993
Nominal Voltage Range	-7 V to +12 V DC
Binary 1 State	Difference voltage > 0.2 V
Binary 0 State	Difference voltage < -0.2 V
Communication Speed	300 to 9600 Baud
Maximum Number of Nodes	31
Maximum Length	1000 m cable (daisy chain)
Insulation	4 kV AC/50 Hz, 1 min
Creepage Distance	6.2 mm
Impulse Voltage Withstand	6 kV peak 1.2/50 μ s
Protocols	IEC62056-21 C

Pulse Output r53	
Type	S0 Interface (or data stream)
Standard	IEC 62053-31
Configurable	Imp/Wh or imp/VArh
Pulse Constant	Configurable (1 – 1000)
Supply Voltage (typ.)	24 V
Supply Voltage (max.)	50 V
Current	10 mA DC
Pulse Length	Configurable (10 ms – 1000 ms)
Maximum Line Length	1000 m

Relay Output (ZMR100xR only)	
Type	Single-pole, single-throw, normally open
Maximum Contact Voltage	276 V _{RMS}
Maximum Contact Current	5 A (30 V DC), 10 A (250 V AC)
Contact/Coil Insulation	Basic
Coil Maximum Power	200 mW
Coil Voltage	12 V _{DC}



Limited suitability of r53 for testing purposes:

The pulse output r53 is only suitable to a limited extent for meter testing due to its special method of operation (refer also to 5.4 *Connecting the meter*).




Figure 1. Pulse shape according to DIN 43 864

2.4.11 Control inputs

External Switching Voltage Values	
Control Voltage (UT)	120-240 V
Range	0.8 – 1.15 (UT)

2.5 Data readout

The Utility Company can take readings from the meter at any time in the field. .MAP110 tool can be used for detailed local readings. There are three possible ways to perform local readings, they are:

- Take readings directly from the LCD display. The registers will either scroll through a configurable loop or the Cycle Display button can be pressed to move through the available registers.
- With the aid of a suitable laptop computer or PDA, more detailed readings can be taken using the optical port. This method of communication is also utilised for the reconfiguration of certain meter functions, for example, reset registers and change tariff details. For the necessary hardware and software, please contact the Landis+Gyr Metering Sales Team who will be happy to assist.

Below is an example of a typical data readout using .MAP110:

Code	Main Value	Auxiliary Value
F.F.0	00000000	
0.0.0	12345678	
0.0.1	87654321	
C.2.0	22	
0.9.2	13-06-25	
0.9.1	11:26:42	
1.8.1	008362.44 kWh	
1.8.2	002633.20 kWh	
1.8.3	001145.14 kWh	
1.8.4	000856.08 kWh	
1.6.0.01	0047.62 kW	
14.7.0	50.2 Hz	
32.7.0	239 V	
52.7.0	234 V	
72.7.0	240 V	
0.2.2	122	
0.1.0	12	
C.61.0	0000	
C.61.2	00000000 min	

Figure 2. Data readout example

3 Safety

3.1 Safety information

The following symbols are used to draw your attention to the relevant danger level, i.e. the severity and probability of any danger, in the individual sections of this document.

**Warning**

Used to indicate a dangerous situation that could cause bodily injury or death.

**Caution**

Used to indicate a situation/ action that could result in material damage or loss of data.

**Note**

Used to indicate general guidelines and other useful information.

In addition to the danger level, safety information also describes the type and source of the danger, its possible consequences and measures for avoiding the danger.

3.2 Responsibilities

The owner of the meters – usually the utility company – is responsible for assuring that all persons engaged in working with meters:

- Have read and understood the relevant sections of the user manual.
- Are appropriately qualified for the work to be performed.
- Strictly observe the safety regulations (laid down in section 3.3) and the operating instructions as specified in the individual sections.

In particular, the owner of the meters bears responsibility for the protection of persons, prevention of material damage and the training of personnel.

For this purpose, Landis+Gyr provides training on a variety of products and solutions. Please contact your local Landis+Gyr representative if interested.

3.3 Safety regulations

The following safety regulations must be observed at all times:

- This equipment does not contain a disconnection device. Means for disconnection from the electricity supply must be provided as part of the building installation. Do not work on the equipment unless the supply is disconnected. If disconnection is done by removal of fuses or other cut-outs, the removed disconnection devices must be kept secure from replacement while work is performed. If disconnection is provided by a switch, the switch shall conform to the requirements of IEC 947-1 and IEC 947-3 or equivalent.
- This equipment does not contain an over-current protection device. Over-current protection must be provided as part of the building installation. Maximum over-current device rating is 125 A at 415 V, conforming to the requirements of BS1361 or equivalent. The meter connections must not be under voltage during installation or when opening. Contact with live parts is dangerous to life. The relevant main fuses should therefore be removed and kept in a safe place until the work is completed, so that other persons cannot replace them unnoticed.
- Only suitably trained and qualified personnel shall be allowed to work on the equipment. Local safety standards shall be observed and shall take precedence over these regulations in points of conflict.
- The meter must be held securely during installation. They can cause injuries if dropped.
- Any meter that has fallen must not be installed, even if no damage is apparent, but must be returned for testing to the service and repair department responsible (or the manufacturer). Internal damage can result in functional disorders or short-circuits.
- The meter must on no account be cleaned with running water or with high-pressure devices. Water penetration can cause short-circuits.
- The meter terminal cover should be secured in place before any load is applied.
- To avoid overheating, the meter must be connected using appropriate cable sizes:
 - Currents up to 60 A: a cable with a minimum 16 mm² cross-sectional area.
 - Currents up to 100 A: a cable with a minimum 25 mm² cross-sectional area.
 - Currents up to 125 A: a cable with a minimum 35 mm² cross-sectional area.

4 Mechanical description

4.1 Meter description



Figure 3. View of the E230 ZxR110CC meter

1. Reactive test output
2. Display
3. Display button
4. Active test output
5. Alert LED
6. Optical interface




Figure 4. View of the E230 ZMR120CR meter

1. Reactive test output
2. Display
3. Display button
4. MD (Maximum Demand) button
5. Active test output
6. Alert LED
7. Optical interface

4.1.1 Meter construction

The meter base, terminal shroud, long hanging bracket and calibration link seal are 10% glass-filled UV stabilised polycarbonate material with a flame retardant (V0) rating. All available terminal covers, the meter cover (top) and short hanging bracket are non-glass filled UV stabilised polycarbonate material with a flame retardant (V0) rating.

4.1.2 Weight and dimensions




Figure 5. Meter with standard terminal cover and extended fixing bracket

Weight Approx.	1	kg
External Dimensions	Comply with DIN 43857	
Width	170	mm
Height (with standard terminal cover)	182.4	mm
Height (with extended terminal cover)	239.1	mm
Height (with extra extended terminal cover)	346.1	mm
Depth	65.5	mm




Figure 6. Terminal layout and phase connections

External Connections	
Type	Screw terminals
Diameter	9.5 mm (Brass), 8.5 mm (Steel)
Torque	Max. 3 Nm

Conductor Cross-section	
Maximum with Brass Terminals	35 mm ²
Maximum with Steel Terminals	25 mm ²
Minimum Conductor Cross-section	1.5 mm ²
Screw Dimensions	M6 x 14
Head Diameter	6 mm
Slot	1.2 mm

4.1.3 Faceplate details

The meter shows type and metrological markings in accordance with MID requirements. The Display button (upper front panel green button) allows the user to scroll through displays as defined in the pre-installed configuration file. The orange MD button (if fitted) is used to reset the Maximum Demand feature (if configured), and can be tamper sealed.

The meters serial number and barcode will be laser marked onto the front of the meter case. Serial numbers are allowed with up to 16 characters.

4.1.4 Purpose of use

The E230 ZxR100AC and ZMR100AR meters record active (ZxR100CC and ZMR100CR also reactive) energy consumption in three-phase four-wire networks. For this purpose, they are directly installed in the supply line by the energy supply company and are read regularly for energy charging purposes. They are particularly suitable for residential metering.

The meter is designed to operate in the following configurations:

Single-Phase Two-Wire	Any phase and neutral
Two-Phase Three-Wire	Any two phases and neutral
Three-Phase No Neutral	Anti-fraud configuration
Three-Phase and Neutral to One Phase (ZFR100xC only)	Delta configuration

Any other application of these meters is not considered use for the intended purpose.

4.1.5 Field of application

The meters can be used for currents up to 125 A (brass terminals) (100 A with steel terminals).

The type designation informs you about the meter's functionality. The extensions define the features/functions of the meter, some of which are optional.

4.2 External connection diagrams (ECD)



The following connection diagrams are examples. The connection diagram relevant for a particular installation is located on the reverse side of the terminal cover.

4.2.1 Single-tariff version




Figure 7. E230 3-phase 4-wire network

4.2.2 Single-tariff version with twin pulse outputs




Figure 8. E230 3-phase 4-wire network, 2 pulse outputs

4.2.3 Multi-tariff version with pulse input, pulse output and CS interface




Figure 9. E230 3-phase 4-wire network, 1 pulse input, 2 pulse outputs and CS

4.2.4 Multi-tariff version with two pulse inputs, two pulse outputs and CS interface




Figure 10. E230 3-phase 4-wire network, 2 pulse inputs, 2 pulse outputs and CS

4.2.5 Multi-tariff version with one pulse input, one relay output and RS485 interface




Figure 11. E230 3-phase 4-wire network, 1 pulse input, 1 relay output and RS485

4.2.6 Multi-tariff version with four pulse inputs and RS485 interface




Figure 12. E230 3-phase 4-wire network, 4 pulse inputs and RS485

5 Installation and commissioning

5.1 Introduction



Do not touch live parts

Dangers exist in live electrical installations the meter is connected to. As a general rule, touching live components is dangerous to life and should be avoided. All local, national and company safety procedures must be observed. This may involve attending suitable training seminars.



The following is a list of the minimum requirements which should be met before any installation is carried out. The observation of local national and company procedures takes a priority over the following and should be observed without fail.

- The procedures described below should only be performed by suitably qualified registered and trained personnel.
- All local national and company safety regulations must be familiar to these persons and strictly adhered to.
- A review of section 3 *Safety* is recommended before commencement.
- Ensure that all tools equipment and materials that maybe required in accordance with section 5.2 are present and in serviceable condition.
- Ensure that the meter type matches to any paperwork supplied and is of the correct type for the installation.
- Confirm all calibration seals are in place and secure.

5.2 Materials and tools required

- An accurate connection diagram (see reverse of terminal cover).
- Correct fixing screws to secure the meter to the meter board or similar.
- Suitable-sized screwdriver.
- Sealing pliers (if required) to affix company seal.
- Suitable drilling machine, if required.
- Test equipment as supplied and as required.

5.3 Mounting the meter



The connecting conductors should not be live during installation of the meter. Electrically live parts are a life threatening hazard. Preliminary fuses should be removed and kept in a safe place, where they cannot be replaced by anyone unnoticed, until all work is complete.

Mount the meter as follows:

1. Find the correct and suitable position to mount the meter.
2. With suitable test equipment, check that the proposed conductors are live. If they are live, remove the preliminary fuses and keep in a safe place where no-one can replace unnoticed until after the work is complete.
3. Mark the fixing points in accordance with the diagram below.




Figure 13. Drilling diagram for fixing screws

4. Drill the holes for the fixing screws
5. Unscrew and remove the meter terminal cover
6. Fix the meter to the meter board or other supplied surface with the fixing screws

5.4 Connecting the meter



Remove preliminary fuses before continuing

The connecting conductors should not be live during the installation of the meter. Electrically live parts are a life threatening hazard. Preliminary fuses should be removed and kept in a safe place, where they cannot be replaced by anyone unnoticed, until all work is complete.

With suitable test equipment, check if the proposed conductors are live. If they are live, remove the preliminary fuses and keep in a safe place where no-one can replace unnoticed until after the work is complete.

Connecting the phase conductors

1. Offer the phase conductors up to the meter, measure to desired length, shorten if necessary and strip back the insulator.
2. Following the External Connection Diagram (ECD), found on the inside of the terminal cover, connect the conductors to the relevant phase connections and tighten the terminal screws firmly (maximum torque 3.0 Nm)




Figure 14. Phase connection diagram



Insufficiently tightened terminal screws at the phase connections can lead to increased power loss at the terminals and therefore undesirable heating. A contact resistance of 1 mΩ causes a power loss of 10 W at 100 A.

Connecting the auxiliary inputs and outputs

1. Offer the phase conductors up to the meter, measure to desired length, shorten if necessary and strip back the insulator.
2. Wires and strands up to 4 mm² can be used.
3. If a stranded conductor is used, it is recommended to terminate the end before inserting into the auxiliary connections.
4. Follow the numbering system as shown on the ECD, which is located on the inside of the terminal cover.

5.5 Final checks before applying power



Only a properly connected meter can operate correctly. Installation errors will result in a financial loss for the utility company.

Ensure the following points are satisfied before powering the meter and correct as necessary.

1. Cross-reference the meter type number and serial number to confirm that the correct meter has been used for the installation.
2. Check the factory fitted calibration seal is in place and secure.
3. Check all phase terminal screws are tightened to the correct torque (max. 3 Nm).
4. Fit terminal cover and seal with company seal if applicable.

5.6 Commissioning and functional check



Do not touch live parts

It is necessary, in order to put the meter into service and perform a functional check, to replace the preliminary fuses. The connecting conductors will therefore become live. Electrically live parts are a life threatening hazard. If any modifications to the installation are required, preliminary fuses should be removed and kept in a safe place, where they cannot be replaced by anyone unnoticed, until all work is complete.

Once satisfied that it is safe to do so, replace the preliminary fuses, and the meter will power on.

The installed meter should be put into service and checked as follows:

1. Insert the preliminary fuses removed for installation. The meter is switched on.
2. Check whether the operating display appears correctly (no error message).
3. Check on the display whether all three phases L1, L2 and L3 are indicated and show the phase sequence.
 - If one phase is not present, the relevant symbol is absent. This is also the case if the voltage is less than 25% U_n .
 - With the normal phase sequence L1-L2-L3 the symbols are displayed continuously.
 - If the meter is connected with a reversed phase sequence (e.g. L2-L1-L3) the symbols flash. The direction of field rotation (clockwise or anticlockwise) is determined by parameterisation. This has no influence, however, on the measuring behaviour of the meter.



Caution

Some of the aids described here are not available depending on the version for a specific country.

4. Connect a load and check the power indicator and energy direction display on the meter.

The power indicator provides a rough idea of the power applied (for values, see section *6.1 Customer display*). With a smaller load, particularly close to starting or no load, the meter requires a little time (up to 10 s) before indicating the relevant value. This also applies to the display of energy direction.

5. Switch off the load again.

If no load is present, the energy direction arrow disappears and the power indicator only shows the upper bar.

6. Check the tariff display and switch the control voltage on and off at the tariff input. The arrow symbol of the tariff display must change.
7. If the meter is operating correctly, screw on the terminal cover. Otherwise first locate and eliminate the error.
8. Seal the terminal cover with two company seals.

5.6.1 Installation mode

This is an optional feature. During a configurable period of up to 240 minutes, the meter will display all energy registers to three decimal places irrespective of the configuration. If the meter is configured this way, every power up occurrence of the meter in the installation mode is triggered for the defined duration of time. However, it is more common and also possible to manually enable and disable the installation mode by formatted command using the .MAP110 meter support tool (see formatted commands “Enable Test Mode” and “Disable Test Mode”).

6 Operation

6.1 Customer display

The meter is fitted with a custom LCD display. A 'display test' is illustrated below showing all segments lit.




Figure 15. E230 ZMR100xR customer display

1. Reactive creep indicator
2. Energy direction indicator
3. Active creep indicator
4. Tamper alert indicator
5. Phase indicator
6. Battery level
7. Register indicator
8. Register value (8 digits)
9. Current register text or OBIS code (5 digits)
 - Rate and/or Relay and/or tamper status indication (triangles)

6.1.1 Display cycle options

Custom configuration options control which registers and parameters that are shown on the display. The meters are factory configured to the utility company's specification. The display sequence and the on screen duration are also dependent on the meter's factory setup. Below is a brief indication of what can be displayed. (Please see the configuration options document for complete options.)

- Channels 1-6 (ZxR100xC) or 1-8 (ZMR100xR)
- Rates 1-4 (ZxR100xC) or 1-6 (ZMR100xR), active rate and total
- IRMS and VRMS per phase
- Power Factor per phase and for all phases
- kW, kVA_r and kVA per phase, summed and total

- Maximum Demand (2 channel in ZxR100xC or 4 channel in ZMR100xR), Previous MD and Cumulative MD
- Maximum Demand per rate, current MD and total MD
- Previous billing (stored values) (ZMR100xR only)

6.1.2 Example displays

To further clarify what information can be obtained from the meter's display, the following are examples of what can appear on the display and a description of what is being represented. As per above, the meter display is subject to factory configuration and therefore all options below may not appear on every meter installation.

For the purpose of this document, a flashing LCD segment will be shown in red colour and illustrated using this symbol:



Energy register indicators can be configured in production to show either text or OBIS codes to identify the current register.

Table 1. Display text and OBIS code correspondence

Register	Display text	OBIS code
Energy Registers	Configurable	See Table 2
VRMS Phase L1	L1	32.7.0
VRMS Phase L2	L2	52.7.0
VRMS Phase L3	L3	72.7.0
IRMS Phase L1	L1	31.7.0
IRMS Phase L2	L2	51.7.0
IRMS Phase L3	L3	71.7.0
Power Factor Phase L1	PF1	33.7.0
Power Factor Phase L2	PF2	53.7.0
Power Factor Phase L3	PF3	73.7.0
Power Factor Phase Summation	PFT	13.7.0
Mains Frequency	FR	14.7.0
ID1.1 Meter ID (8 characters)	ID1.1	0.0.0
ID1.2 Customer ID_1 (characters 1-8)	ID1.2	0.0.1
ID1.3 Customer ID_2 (characters 9-16)	ID1.3	0.0.2
ID1.4 Manufacturing ID (8 characters)	ID1.4	0.0.3
ID 2.1 Identification Number 2.1	ID2.1	C.1.0
ID 2.2 Identification Number 2.2	ID2.2	C.1.1
IEC Device Address	IEC	C.90.1

Register	Display text	OBIS code
Software ID	VER	0.2.0
Config ID	C OPT	C.90
Last Configuration Change ID	C.128.0	C.128.0
Parameter ID	P ID	0.2.1
Parameter Count (ZMR100xR only)	NUM P	C.2.0
Date (ZMR100xR only)	DATE	0.9.2
Time (ZMR100xR only)	TIME	0.9.1
Billing Period Reset Count	RST	0.1.0
Blank Display	No Legend	
All Segments On	All Seg. On	
Phase L1 kW	L1	36.7.0
Phase L2 kW	L2	56.7.0
Phase L3 kW	L3	76.7.0
Summation kW	LT	16.7.0
Total (L1+L2+L3) kW (magnitude)	TOT	16.7.0
Phase L1 kVAr	L1	151.7.0
Phase L2 kVAr	L2	171.7.0
Phase L3 kVAr	L3	191.7.0
Summation kVAr	LT	131.7.0
Total (L1+L2+L3) kVAr (magnitude)	TOT	131.7.0
Phase L1 kVA	L1	29.7.0
Phase L2 kVA	L2	49.7.0
Phase L3 kVA	L3	69.7.0
Summation kVA	LT	9.7.0
Total (L1+L2+L3) kVA (magnitude)	TOT	9.7.0
Error	ERROR	F.F.0
Alert Status	C.10.1	C.10.1
DC Field Count	DC D	C.60.0
DC Field Running Time	DC RT	C.60.1
DC Field Cumulative Time	DC CT	C.60.2
Terminal Tamper Count	TT R	C.61.0
Terminal Tamper Running Time	TT RT	C.61.1
Terminal Tamper Cumulative Time	TT CT	C.61.2
Meter Case Tamper Count	TC R	C.62.0
Meter Case Tamper Running Time	TC RT	C.62.1

Register	Display text	OBIS code
Meter Case Tamper Cumulative Time	TC CT	C.62.2
Operating Status	S OP	C.5.0
I / O Status	S IO	C.3.0
Control Status	S CTL	C.4.0
Power Fail Count (all phases)	POC	C.7.0
Phase L1 Fail Count	PFC1	C.7.1
Phase L2 Fail Count	PFC2	C.7.2
Phase L3 Fail Count	PFC3	C.7.3
Total Operating Time	OPT	C.8.0
Rate 1 Operating Time	OP1	C.8.1
Rate 2 Operating Time	OP2	C.8.2
Rate 3 Operating Time	OP3	C.8.3
Rate 4 Operating Time	OP4	C.8.4
Rate 5 Operating Time (ZMR100xR only)	OP5	C.8.5
Rate 6 Operating Time (ZMR100xR only)	OP6	C.8.6
Billing Period Average Power Factor	AV PF	13.0.0
Reverse Current Counter	REV C	C.64.0
EDL21 Total Active Power (summation)	P	P
EDL21 (Consumption Start 1) Import 1 (ZxR100xC only)	E	E
EDL21 (Consumption Start 2) Export 2 (ZxR100xC only)	E-E	E-E
EDL21 (Consumption Day) Import (ZxR100xC only)	1 d	1 d
EDL21 (Consumption Week) Import (ZxR100xC only)	7 d	7 d
EDL21 (Consumption Month) Import (ZxR100xC only)	30 d	30 d
Active TOU Activation Date (ZMR100xR only)	AT AD	C.2.2
Active TOU ID (ZMR100xR only)	AT ID	0.2.2
Passive TOU Activation Date (ZMR100xR only)	PT AD	C.2.7
Passive TOU ID (ZMR100xR only)	PT ID	0.2.7

Table 2. Determining OBIS code for energy registers

1st digit	Significance	2nd digit	Significance	3rd digit	Significance
1	A+	2	Max demand	1	Tariff 1
2	A-	8	Cumulative energy	2	Tariff 2
3	R+	9	Periodic	3	Tariff 3
4	R-			4	Tariff 4
				5	Tariff 5
				6	Tariff 6

For example: OBIS code 2.8.1 means A-, cumulative energy, tariff 1.

6.1.3 Energy efficiency meter displays (ZMR100xC only)

If configured appropriately, the display can list 6 new (Software \geq K76) items intended to allow the consumer to easily monitor energy consumption:

Item	Display	Content	Remarks
EDL21 Total Active Power (Summation)	P	Total Active Power (Summation)	None
Import Energy Meter	E	Import Energy 1.8.0	Resettable
Export Energy Meter	E-E	Export Energy 2.8.0	Resettable
24 Hour Energy Consumption	1 d	Import Energy 1.8.0 over last 24 h	Refresh every 5 min
1 Week Energy Consumption	7 d	Import Energy 1.8.0 over last week	Refresh every 1 hour
1 Month Energy Consumption	30 d	Import Energy 1.8.0 over last month	Refresh every 1 hour

The resolution of these 6 displays is 1 W.

30 d and P registers are available in firmware version K76 or newer.

As a built-in privacy feature, if any EDL21 display is shown in conjunction with no display button activity (presses) for 120 seconds, the meter exits the EDL displays and returns to the Main Display list.


6.1.4 Meter powered with zero energy being consumed (anti-creep mode)

Example A shows that the meter is powered on all 3 phases (L1-L2-L3), the internal battery is in maximum charge state (4 bars) (optional feature) and that the current register being displayed is a kWh register. In a reverse phase situation (e.g. L1-L3-L2), the phase power segments will flash.

The phase voltage indications are switched on, if the respective phase voltages are present. It can be selected by parameterisation whether all the phase voltage indications are flashing, if the rotating field goes in the wrong direction, and/or whether they are flashing, if the energy flow is reversed in the corresponding phase. The meter can also be configured so that it will flash in service mode only.

The significance of the two segments A and B (a diamond and a circle) is to show that both the kVARh (diamond) (reactive measurement is an option) and the kWh (circle) registers have entered anti-creep mode. Zero energy is flowing through the meter, which is further illustrated by the lack of any energy direction indicator.

Example A (OBIS code 1.8.1)



To introduce the function of the direction indicators, we move to the display below (example B). The Reactive Register is still in anti-creep mode (diamond symbol and lack of reactive direction indicators).

The Active Register is, however, now measuring energy. The circle symbol is no longer lit and we have direction indicators +P and -P. The +P indicator is solid 'on', which indicates that the instantaneous active energy is predominantly in a positive direction (phases summed). The -P indicator is flashing, which indicates that there is an amount of reverse energy being measured, but it is less than the forward energy.

Example B (OBIS code 1.8.1)



Possible states for the +/-P indicators are:

Both off	No Active Energy is being consumed.
+P 'on' -P 'off'	All energy being consumed is in a positive direction.
-P 'on' +P 'off'	All energy being consumed is in a negative direction.
+P 'on' -P flashing	Majority of the energy is Positive with some negative (only in three-phase four-wire circuit; only with magnitude summation).
-P 'on' +P flashing	Majority of the energy is Negative with some positive (only in three-phase four-wire circuit; only with magnitude summation).

Example C below is the reciprocal of the previous. Active energy is now zero (circle symbol and no direction indicators (anti-creep mode)), but Reactive energy is now being recorded. Again the arrow and +Q symbols are flashing.

Also notice that the displayed register is now a positive total kVArh register.

Example C (OBIS code 3.8.1)



Possible states for the +/-Q indicators are:

Both off	No Reactive Energy is being consumed.
+Q 'on' -Q 'off'	All energy being consumed is in a positive direction.
-Q 'on' +Q 'off'	All energy being consumed is in a negative direction.
+Q 'on' -Q flashing	Majority of the energy is Positive with some negative (only in three-phase four-wire circuit; only with magnitude summation).
-Q 'on' +Q flashing	Majority of the energy is Negative with some positive (only in three-phase four-wire circuit; only with magnitude summation).

The Energy Direction Indicators (or anti creep indicators) will always be displayed. These indicators, along with the phase powered indicators (L1, L2, L3), battery monitor and rate indicators (see below) provide the user with a quick overall status of the meter.

6.1.5 Total registers

The display is now showing the Active Reverse Total register (example D). Notice that the meter is also recording Majority Positive Active and Majority Positive Reactive Energy and that the battery level indicator has changed to 2 bars.

Example D (OBIS code 2.8.1)



Reactive positive total display

Example E (OBIS code 3.8.1)



Active forward total display

Example F (OBIS code 1.8.1)



Reactive negative total display

Example G (OBIS code 4.8.1)



Apparent energy total display


Example H (OBIS code 3.8.1)



6.1.6 Rate registers

There are six inverted triangles at the bottom left of the display, indicated as A B C, D, E and F in the display examples (example I) below. When configured to be used, these segments can be used to indicate current active rate, relay status, case and terminal cover tamper indication or a combination of these conditions where applicable. More details are provided in the Functional Description document. As with the energy direction indicators, these segments are independent of the remainder of the display, and provide a quick indication of the rate, relay and tamper status that the meter is currently in (configuration option).

Example I (OBIS code 1.8.3)



To represent the Rate registers, the display will appear as in example J. Here we have Rate 3 Forward Active Energy register.

The energy direction indicators are incidental to this (and any other) display mode, and are showing current energy consumption (Reactive in anti-creep mode, Majority Forward with some Reverse Active energy in this example).

Example J (OBIS code 1.8.3)



Rate 1 reactive negative

Example K (OBIS code 4.8.1)




6.1.7 Instantaneous values

If configured to do so, the meter can display various instantaneous values. Examples of these are shown below:


T-phase (L3) reactive power (+/- summed)

Example L (OBIS code 191.7.3)




R-phase (L1) active power (forward / reverse summed)

Example M (OBIS code 36.7.0)




Instantaneous apparent power (phase summed)

Example N (OBIS code 131.7.0)




Instantaneous phase voltage (L2 in this example)

Example O (OBIS code 52.7.0)



Instantaneous average current (across all 3 phases)

Example P (OBIS code 12.7.1)




Instantaneous power factor (individual phase; phase T (L3) in this example)

Example Q (OBIS code 73.7.0)



Instantaneous supply frequency average

Example R (OBIS code 14.7.0)




6.1.8 Maximum demand displays

Maximum Demand (MD) is a hardware and software option, and is factory fitted. The following will demonstrate how various MD displays will appear. In all the examples, kW has been measured. The meter can be configured to measure kVAr.


Maximum demand rate 2

Example S




Maximum demand total

Example T




Previous maximum total

Example U



Cumulative maximum demand

Example V




6.1.9 Alert / report and test displays

The following displays are examples of miscellaneous counters that the meter stores. They can all be factory configured to be part of the meter's display cycle. Some of the following options will also require the relevant hardware, which must be factory fitted.

Terminal cover tamper count

Example W (OBIS code 82.8.1)



Signal Input					
Measurement channel 1	Measurement channel 2	Measurement channel 3	Measurement channel 4	Measurement channel 5	Measurement channel 6
Rate register 1					
Rate register 2					
Rate register 3					
Rate register 4					
Total register					

6.3 Push button operation

The meter is fitted with up to two push buttons. The green Display button (blue in pre-Release 2 meters) is used for stepping through the meter's display cycle. Each press will advance the configured display sequence by one display.

The standard display cycle is configurable with a maximum of 32 (ZxR100xC) or 64 (ZMR100xR) displays. There is an option to have an extended display cycle. The extended cycle is a maximum 64 (ZxR100xC) or 128 (ZMR100xR) displays and is accessed by pushing and holding down the Display button for ≥ 3 seconds.

If the display sequence has been partially cycled and the push button is not pressed for a period of time, the display sequence will revert to the default display.

The orange MD button (if fitted) can be used to perform MTDP (Manual Time and Date Programming) (ZMR100xR only), accessing P3 security level (ZMR100xR only) and resetting of Maximum Demand/Manual Billing reset, see section 6.7.4. If parameterised, the MD button can be used to reset alerts in the installation mode when "End" or "All Segments" are displayed (ZMR100xR only). The MD button is an optional feature and allows for fitment of a wire and ferule (or similar) utility seal.

6.4 Tamper detection

6.4.1 Reverse energy detection (RED)

If the meter is configured to operate in Reverse Energy fraud detection mode, the meter will alternate a warning message on the display if a fraud attempt is made by running current backwards through the meter. The reverse energy warning message is triggered when the reverse power exceeds a programmable threshold level of between 1-10 Amps for a period of 10 seconds. The meter will store the number of RED (Reverse Energy Detected) tamper events.

Once triggered, the reverse energy-warning message can only be reset by a formatted command.

6.4.2 Tamper event log (ZMR100xR only)

All meters with an internal RTC have a tamper event log, where the date/time, status and number of events are stored. The maximum capacity of the log is 200 events. The event log can be read and cleared through the communication interfaces with appropriate rights, but it is not displayed on the LCD.

The following events can be recorded in the log depending on the device settings and configuration. The events trigger a log event either when they begin or both when they begin and end.

Event no.	Name	Description	Trigger	Event	Anti-fraud	Perma- nent trigger (confi- gurable)
1	Voltage imbalance	Indicates that any phase voltage is below the % threshold of Max Voltage.			X	X
2	Energy registers cleared	Indicates that tariff energy registers were cleared (but not the total energy registers).		X		
3	Load profile and/or stored value profile cleared	Indicates that the load profile and/or the stored value profile was cleared.		X		
4	Event log cleared	Indicates that the event log was cleared. This is always the first entry in the event log.		X		
5	Battery low	Indicates that the battery voltage fell below a set threshold.		X		
6	Current imbalance	Indicates that any phase current is below the % threshold of Max Current.			X	X

Event no.	Name	Description	Trigger	Event	Anti-fraud	Permanent trigger (configurable)
8	Billing period reset	Indicates that a billing period reset has occurred.		X		
9	Daylight saving time enabled or disabled	Indicates a change from and to daylight saving time. The time stamp shows the time before the change.		X		
10	Clock adjusted (old date/time)	Indicates that the date/time has been adjusted. The time that is stored in the event log is the old time before the adjustment was made.		X		
11	Clock adjusted (new date/time)	Indicates that the date/time has been adjusted. The time that is stored in the event log is the new time after the adjustment was made.		X		
17, 18, 19	Under-voltage L1, L2, L3	Indicates that an undervoltage has occurred on the corresponding phase.		X		
20, 21, 22	Overvoltage L1, L2, L3	Indicates that an overvoltage has occurred on the corresponding phase.		X		
23	Power down	Indicates that a power failure has occurred.		X		
24	Power up	Indicates that a power up has occurred.		X		
25, 26, 27	Overcurrent L1, L2, L3	Indicates that an overcurrent has occurred on the corresponding phase.		X		
28, 29, 30	Voltage without current L1, L2, L3	Indicates a possible shorting of the current coil.			X	X
31	Power factor monitor 1	Indicates that the power factor is below a set limit.		X		
33, 34, 35, 36	Demand monitors 1, 2, 3 and 4	Indicates that the demand is above a set limit.		X		
37, 38, 39	Phase reversal L1, L2, L3	Indicates a reversal of polarity of the current coil.			X	X

Event no.	Name	Description	Trigger	Event	Anti-fraud	Permanent trigger (configurable)
40	Parameter changed	Indicates that one or more parameters have been changed by an external tool. The event is triggered by the tool.		X		
45	Error Register Cleared	Indicates that the error register (F.F.0) has been cleared.		X		
49, 50, 51	Missing voltage L1, L2, L3	Indicates that the corresponding voltage dropped below 20 V and remained below 20 V for a period of time defined by parameterisation.			X	X
55	Magnet detection	Indicates that the meter has been influenced by a strong magnet (>0.5T). If event 55 is recorded without event 134, a tamper/fraud attempt has been made, but energy measurement has not been affected.			X	X
66	Date/time invalid	Error		X		
76	Time base error	Error		X		
89	Start-up sequence invalid	Error		X		
133	Terminal cover removal	Indicates that the terminal cover has been removed.			X	X
134	Strong DC field	Indicates that the energy measurement ICs have been affected by the presence of a strong DC magnet. Energy measurement must be treated as though it has been tampered with, which may result in inaccurate energy measurements from the point of detection.			X	X
135	Front cover removal	Indicates that the front cover has been removed.			X	X

With the occurrence of event 66 (Date/time invalid) RTC failure, all events except events 9, 10, 11 and 33-36 continue to be logged, but do not necessarily have valid date and time stamps. Tamper persistence times will also not be logged. To prevent the event log from filling as a result of event 66, events 66, 76 and 89 are only recorded once, until the clear event log is performed.

6.4.3 Meter cover opening (optional fitting)

A switch can be fitted to the meter, which will open when the top cover is removed. The meter will record the number of times the switch is activated. This feature is incorporated into the battery back-up circuit and is therefore operational even with no mains supply to the meter. If the tamper is triggered during a power fail situation, the meter will only detect one alert. For example, if the cover is removed and then replaced and then removed again, only one tamper count will be recorded. The tamper register will need to be reset when power has been restored in order for it to begin registering any further no power alerts.

6.4.4 Terminal cover opening (optional fitting)

A similar circuit to the above applied to the Terminal Cover.

6.4.5 DC magnetic field intrusion

The meter will detect the presence of a strong DC magnetic field and can be used to activate the tamper Alert. There are two separate detection methods, each having a separate event number: Magnet detection (event 55) and Strong DC Field (event 134). Event 55 is the first indication of a potential tamper attempt. Event 134 indicates that the energy measurement ICs have been affected by the presence of a strong DC magnet. Energy measurement must be treated as though it has been tampered with, which may result in inaccurate energy measurement from the point of detection.

6.4.6 Alert notification

The meter can be configured to activate the front panel Alert LED, when an alert is detected, and/or illuminate the Bell alert icon on the meter display. Any combination of the following alerts can be configured:

- Meter Cover Tamper
- Terminal Cover Tamper
- DC Field (Magnetic fraud)
- Voltage Missing (ZMR100xR only)
- Phase Reversal (ZMR100xR only)
- Voltage Without Current (ZMR100xR only)
- Voltage Imbalance (ZMR100xR only)
- Current Imbalance (ZMR100xR only)

With the exception of meter cover tamper, terminal cover tamper and DC field, all alerts/events have separate definable thresholds and include:

- Missing voltage persistence time
- Voltage without current persistence time
- Under voltage persistence time
- Current threshold for voltage without current
- Over voltage persistence time
- Phase reversal persistence time
- Under voltage threshold voltage
- KVA threshold for PF monitor
- Over voltage threshold voltage
- Threshold for PF monitor
- Over current persistence time
- Voltage imbalance persistence time
- Over current threshold current
- Lower power factor persistence time
- Current balance persistence time
- Power On/Off persistence time
- Magnet sensor persistence time
- Voltage unbalance threshold (V_{\max})
- Current imbalance threshold (I_{\max})
- Threshold for demand monitor Ch1
- Threshold for demand monitor Ch2
- Threshold for demand monitor Ch3
- Threshold for demand monitor Ch4

6.5 No power read (optional fitting)

The No Power Read (NPR) feature allows readings to be taken from the meter for data collection purposes either via the optical port or from the LCD display, when there is no mains supply. This function is activated by pressing and holding the display cycle button or by using the front panel optical port.

The battery circuitry locks on after about 2 or 3 seconds and provides about 60 seconds of power in which to read the meter or perform a flag download. In No Power Read mode, the display sign-on is removed to conserve power. After this, the display uses the NPR default display and NPR display cycle. Some functions of the meter are disabled in this mode (e.g. LEDs and Relays).

After using the battery, a repeat operation cannot be performed for approximately 60 seconds. To prolong battery life, the number of times NPR can be activated is restricted to 2 per month.

6.6 ToU (Time-of-Use) tables (ZMR100xR only)

The E230 ZMR100xR's ToU functionality provides a maximum of 16 output signals to switch:

- Energy
- Demand tariffs
- Control loads

A maximum of 6 day tables can be used, e.g. for weekdays, Saturday, Sunday and holidays. In each day table, it is possible to define up to 24 switching times. During one year, it is possible to define up to 12 different seasons, where for each day (Monday to Sunday) a day table is chosen. An exception day table with up to 200 entry days (e.g. national holidays, Easter Monday, New Year's Day, etc.) can be defined and it overrules the season and day tables.

There are two complete sets of switching tables:

- Active switching tables: Active switching tables are the ones that are currently being used.
- Passive switching tables: Passive switching tables are not yet used. They can be prepared in the background for later use.

Each set of switching tables bears an ID code with which it is clearly identified. The ID code consists of a maximum of 7 characters and can be set by a tool.

- The passive switching tables will be activated, if the current date becomes newer than the activation date. An activation date set in the past or today will therefore immediately activate the passive switching tables.
- There are no passive special day settings. Therefore, a special day setting becomes active immediately after you have completed its definition.

The time resolution in a day table is 15 minutes. Each line in the day table represents one switching state with its start time and the activated signals in that period of time. The first entry starts at 00:00 hours and the last entry ends at 24:00 hours.

Day Table n								
Valid from	TOU-T1	TOU-T2	TOU-T3	TOU-T...	TOU-T...	TOU-T...	TOU-T15	TOU-T16
00:00								
06:00	x							
11:00	x							
13:00								

The day tables are controlled by the exception days and season tables. The exception day table has priority over the season day table.

The exception day table is used to define a tariff to be used on a particular day, e.g. national holiday, Easter Monday, etc. If the date includes the year, the special day is valid for the specified year only (e.g. Easter). If the date does not include the year, the special day is valid every year thereafter (e.g. New Year).

At each change of the date, the time switch checks whether or not the following day is a special day and selects the day table accordingly.

Date	Day Table
01.01.	2
25.12.	2
25.3.2007	3
15.3.2008	1

A maximum of 200 exception days can be programmed.

The season table defines the weekly and the seasonal on/off pattern of the control signals.

- **Week:** To define the weekly on/off pattern, the user enters the number of the day table which is applicable on a particular day of the week. As soon as all days of the week are allocated with a day table, the week table is completed.
- **Season:** In the season column, the user defines the period of the year the week table applies to. A maximum of 12 seasons can be defined.

Season Table							
Season	Mon	Tue	Wed	Thu	Fri	Sat	Sun
01.01. – 31.03.	1	1	1	1	1	2	2
01.04. – 30.09.	3	3	3	3	3	2	2
01.10. – 31.12.	1	1	1	1	1	2	2

If the meter's internal clock fails, an emergency table is used. These settings remain active until the clock has been adjusted.

Emergency Settings							
TOU-T1	TOU-T2	TOU-T3	TOU-T4	TOU-T5	TOU-T6	TOU-T7	TOU-T8
x	x			x			

6.6.1 Tariff control (ZMR100xR only)

E230 ZMR100xR can have up to six different tariff rates for energy depending on the type. The meter has built in ToU tables that can control tariffs, but tariffs can also be controlled by signals from other sources. The meter also has external control inputs for tariff switching.

The control sources for tariff control are:

- Time of use signals
- Voltage monitors
- Anti-fraud inputs
- Demand monitor
- Power factor monitor

Time-of-Use has up to 16 Time switch signals for controlling tariffs.

Voltage monitors produce Events signals due to over- and under-voltage, missing voltages (phase losses) and total phase failure (total power loss).

Tampering inputs produce Events signals due to strong DC fields, as well as meter and terminal cover or meter box opening.

Demand monitors produce Event signals indicating a high demand value (two demand excess monitors based on the average demand).

Power factor monitor produces Event signals indicating too low power factor value. The various control sources or a combination of them can be used to enable and disable registers, to control arrows on the LCD and the Alert LED, and to control outputs.

6.6.2 Load control (ZMR100xR only)

The meter's external outputs can be controlled by:

- TOU signals
- Control input signals
- Combination of tariff signals
- Event signals
 - Time/date not valid
 - Demand monitor
 - Power factor monitor
 - Voltage monitoring
 - Tamper monitoring
 - Alert occurred

6.7 Maximum demand

Maximum Demand (MD) can be measured in kW, kVAr or kVA. MD functionality is available in two different ways either 'Slab' or 'Rolling'. Both of these, however, use the same registers and settings.

Registers (matching the number of rates available, plus total) in E² are made available for up to four rates and total (ZxR100xC) or up to six rates (ZMR100xR). Current, Previous and Summation MD values are recorded and are available for display and readout.

6.7.1 'Slab' maximum demand

This MD method works by calculating the maximum demand over fixed periods. The Maximum Demand Period is set to the period (in minutes) over which to calculate the MD. This value must be a factor of 60 (i.e. 1, 2, 3, 4, 5, 6, 10, 12, 15, 20, 30 or 60).

The demand is then calculated at this interval in such a way that one of the calculations is done on the hour boundary (e.g. if the period is 12 then the demand is calculated at 0, 12, 24, 36 and 48 minutes past the hour).

For total maximum demand, the recording can either start on power up or not until the first one of these boundaries occurs. In the former case, the demand is calculated by integrating the recorded value over the full period (assuming the rest of the period to be 0).

During each integration period, a rising demand is calculated. This rising demand is what the demand will be if there is no further energy consumption within the current MD period.

Each time the demand is calculated the value is compared to the respective current largest demand, and if it is larger, the new value is written to the register.

6.7.2 'Rolling' maximum demand

Rolling Maximum Demand is always calculated over a period of 15 minutes. The demand is calculated every minute using readings from the last 15 minutes. The first calculation occurs 15 minutes after power up.

Each time the demand is calculated, the value is compared to the respective current largest demand, and if it is larger, the new value is written to the register.

When Rolling Maximum Demand is used, it is not possible to trigger rate switching from an MD activity.

6.7.3 Maximum demand at power fail

If 'slab' MD and partial MD periods are enabled when the power is removed from the meter and then restored, the meter restores the values from the partial period and integrates that as if it were the total energy used over the complete period.

6.7.4 Reset of maximum demand

There are two available methods of resetting maximum demand: Formatted Command via optical port and MD Push Button.

Optical port formatted command

The Maximum Demand registers can be reset via the optical port by formatted command using .MAP110.

MD push button

If the meter is fitted with a Maximum Demand push button, pressing the button for > 3 seconds will reset the MD registers. Once the button is pressed, the button is not active (for further MD resets) until a new MD period has elapsed.

Resetting the maximum demand registers causes the following:

- MD reset count is incremented by one
- Display shows 'rSt PASS' to indicate successful acknowledgement of a manual reset. (If manual reset is not successful, the display will show 'rSt FAIL').

- Old maximum demand values are added to the cumulative registers
- Continual demand register is stored in the Previous MD register
- Current MD registers are then cleared

6.8 Billing (stored values) (ZMR100xR only)

A total of 15 billing (stored values) are available via IEC readout and in the LCD. Billing periods can be closed/reset automatically by means of a configured date and time each month or at a specific time on the last calendar day of the month. Manual closure/reset is also possible by formatted command and use of the orange MD button (where fitted).

Each billing capture will always contain a date and time stamp and a billing reset count number. In addition, they may be defined with any combination of the following parameters (maximum 10):

- Energy register channel 1-8, for up to six rates each, plus total registers
- MD register channel 1-4, for up to six rates each, plus total registers
- Operating time registers for up to six rates, plus total register
- Average power factor
- Battery operating time
- Terminal cover removal event (special Bulgarian parameter)

Since there are a limited number of segments available in the OBIS legend, implementation of a 2 second toggle between parts of the OBIS designation in both auto cycle and manual cycle modes of the displays for all previous billing parameters, is made (excluding the mandatory date/time and reset counter parameters). The last completed billing period is always first in previous billing display list. A worked example is provided below:

Readout
0.1.0 10 (12-12-01;00:00)
0.1.0 10 (10)
1.8.0 10 (000010.55*kWh)
2.8.0 10 (000002.22*kWh)
15.8.0 10 (000002.16*kvarh)
5.8.0 10 (000002.70*kvarh)
6.8.0 10 (000017.69*kVAh)
7.8.0 10 (000010.55*kWh)
8.8.0 10 (000002.22*kWh)
130.8.0 10 (000002.16*kvarh)
C.8.0 10 (00000033)
C.8.1 10 (00000000)

Example Readout

Display	Behaviour
0.1.0 10 (12-12-01;00:00)	No toggle
0.1.0 10 (10)	No toggle
1.8.0 (000010.55*kWh)	2 sec toggle
2.8.0 (000002.22*kWh)	2 sec toggle
15.8.0 (000002.16*kvarh)	2 sec toggle
5.8.0 (000002.70*kvarh)	2 sec toggle
6.8.0 (000017.69*kVAh)	2 sec toggle
7.8.0 (000010.55*kWh)	2 sec toggle
8.8.0 (000002.22*kWh)	2 sec toggle
130.8.0 (000002.16*kvarh)	2 sec toggle
C.8.0 (00000033)	2 sec toggle
C.8.1 (00000000)	2 sec toggle

How the stored values are displayed to the LCD

OBIS Legend					
0	1	0	1	0	
0	1	0	1	0	
1	8	0			2 sec
			1	0	2 sec
1	8	0			2 sec

OBIS legend behaviour (toggling)

All OBIS codes are to be forced left aligned. Billing count/reset count number is to be forced right aligned to make reading clearer.

Manual and Automatic resets are not distinguishable via the display (i.e. it is not possible to display “*” and/or “&” symbols).

Only closed previous billing periods are made visible in the display and IEC readout.

6.8.1 Unit suppression

IEC billing readout may be parameterised to suppress values to suit reading preference or simplify data capture for utility acquisition.

Example billing readout	Comments/remarks
1.6.0(02.250*kW)(11-12-28 12:00)	Units of stored values included (Suppress Units In Billing disabled). Current value must always contain unit, e.g. kW.
1.6.0*21(02.160*kW) (11-11-28 12:00)	Stored value with units.
1.6.0*20(02.015*kW) (11-10-28 12:00)	Stored value with units.
1.6.0(02.250*kW)(11-12-28 12:00)	Units of stored values not included (Suppress Units In Billing enabled). Current value must always contain unit, e.g. kW.
1.6.0*21(02.160) (11-11-28 12:00)	Stored value without units.
1.6.0*20(02.015) (11-10-28 12:00)	Stored value without units.

6.9 MDTP (Manual Date Time Programming) (ZMR100xR only)

The Date, Time and IDs can be programmed using the meter's push buttons. The meter must feature a Maximum Demand button to perform this operation. Configuration is required to enable/disable this feature. A log records the number of times the Date and/or Time is reprogrammed. This is displayed with the first and second displays during MDTP. "rdt" is the date when the last date or time parameter has been changed by MDTP. "rct" is the count/number of changes made to date or time since reset. The count goes up to 99 before rolling over to 00.

6.9.1 Manual setting of date/time/ID

The procedure is as follows (assuming feature is enabled):

After one short press (< 3 seconds) of the Maximum Demand push button, the meter enters a separate display cycle. The display list shows all of the parameters that can be programmed through the MDTP mode.

Subsequent short presses (< 3 seconds) of the Maximum Demand push button will advance the display to the next parameter. The parameter list is sequenced as follows:

- "rdt" - Reprogramming date: date of last programming (read only)
- "rct" - Reprogramming counts: the number of times the Date or Time has been programmed via the push button (read only)
- Date* (0.9.2)
- Time* (0.9.1)
- ID1.1 (0.0.0)
- ID1.2 (0.0.1)
- ID1.3 (0.0.2)
- ID1.4 (0.0.3)
- ID2.1 (C.1.0)
- ID2.2 (C.1.1)

* ZMR100xR only.

At the end of the list, the meter will revert back to Normal Mode. If no buttons are pressed for 10 seconds during the Programming mode, the meter reverts back to the Normal display mode and the changes made during that particular update session will be discarded.

The operation of the Date/Time Programming mode button can be simplified with the following diagram:




Figure 16. Date/time programming mode button operation



Figure 17. Normal mode display



Figure 18. Set mode display



Figure 19. Program mode display

Dashed arrows represent a press of the green Display button.

Solid arrows represent a press of the orange Maximum Demand button.

Thin arrows represent a short button press (<3s).

Thick arrows represent a long button press (>3s).




Figure 20. Date/time programming success/fail sequence

The Success/Fail message confirms the validity of the programmed data. A fail message will revert the display back to Display 1 in 5 seconds. Successful timeout is 10 seconds.

6.10 Front panel optical port

Type	LED / PTR optical port
Standard	IEC1107
Communication protocol	Asynchronous serial
Communication speed	Configurable – 9600 baud max.
16 byte device address	Configurable

6.11 Relays (ZMR100xR only)

The meter can have up to two relays for switching, e.g. load control.

6.11.1 Relay control (ZMR100xR only)

The relay is controlled through six relay sources. These are:




- Rate Switching Patterns (RS)
- Clock Invalid (CI)
- Alert (AL)
- MD Period (MD)
- Energy Direction (ED)
- TOU Switching (TS)

The relay Open/Closed state is decided by the source that controls a particular relay and can optionally be indicated using the triangular indicators detailed in section 6.1.6. This source is freely configurable.







The duration of the open and closed times of the relay can be configured (Clock Invalid (CI), Alert (AL) and MD Period (MD) sources only).

6.12 Energy measurement modes


6.12.1 Vectorial sum

	Quadrants	Direction	Value	Phase	Unit
Channel 1		Import, Q1+Q4	+ A	Sum	kWh
Channel 2		Export, Q2+Q3	- A	Sum	kWh
Channels 3 to 6 (can be configured)		-			







6.12.2 Complete four-quadrant system

	Quadrants	Direction	Value	Phase	Unit
Channel 1		Import, Q1+Q4	+ A	Sum	kWh
Channel 2		Export, Q2+Q3	A	Sum	kWh
Channel 3		Import, Q1	+ R	Sum	kVAr
Channel 4		Import, Q2	+ R	Sum	kVAr
Channel 5		Export, Q3	R	Sum	kVAr
Channel 6		Export, Q4	- R	Sum	kVAr







6.12.3 v1- or always positive registration, absolute value (SUM [ALi])

	Quadrants	Direction	Value	Phase	Unit
Channel 1		Import, Q1-Q4	+ A	L1,L2, L3	kWh
Channels 2 to 6 (can be configured)		-			

6.12.4 Import and export values

	Quadrants	Direction	Value	Phase	Unit
Channel 1		Import, Q1+Q4	+ A	Sum	kWh
Channel 2		Export, Q2+Q3	A	Sum	kWh
Channel 3		Import, Q1+Q2	+ R	Sum	kVAr
Channel 4		Export, Q3+Q4	+ R	Sum	kVAr
Channel 5		Import, Q1+Q4	+ S	Sum	kVA
Channel 6		Export, Q2+Q4	- S	Sum	kVA

6.12.5 Energy consumption plus green energy generation

	Quadrants	Direction	Value	Phase	Unit
Channel 1		Import, Q1+Q4	+ A	L2+L3	kWh
Channel 2		Export, Q2+Q3	A	L1	kWh
Channel 3		Import, Q1+Q2	+ R	L2+L2	kVAr
Channel 4		Import, Q1+Q2	+ R	L1	kVAr
Channel 5		Export, Q3+Q4	- R	L2+L3	kVAr
Channel 6		Export, Q3+Q4	- R	L1	kVAr

6.13 Communication interfaces

The E230 meter has several different communication interfaces:

- Optical test output
- Optical interface
- CS interface (optional)
- RS485 interface (optional)
- S0 interface (optional)

The optical test output is for verifying the meter operation. The LED flashes at 1000 imp/kWh.

The optical interface can be used for gathering the meter data in the field. It is also commonly used for making re-parameterisations and for the input of formatted commands. The readout protocol is according to IEC 62056-21 with speeds of up to 9600 bps.

The CS and RS485 interfaces are both optional and can be used for gathering the meter data in the field. The readout protocol is according to IEC 62056-21 with speeds of up to 9600 bps (4800 bps), but, of course, are highly influenced and dependent on the given installation conditions, cable lengths, etc.

The S0 interface is also optional and can be individually parameterised for a range of pulse frequencies and pulse durations. In addition, pulse output 1 S0 interface may also be used for periodical data output, i.e. the retransmission of data protocol every 30 seconds at 300 bps. This replicates a proprietary communication data stream as found in the obsolete ZME meter.

CS connections

Connection type: screwless terminals.

Designation	Connection
40	+ve
41	-ve

RS485 connections

Connection type: screwless terminals. Terminals are doubled up in order to facilitate the ability to connect in and out (loop) of the meter without compromising the connection quality.

Designation	Connection
27	-ve
28	Ground
29	+ve

S0 connections

Connection type: screwless terminals.

Designation	Connection
20	Pulse output 1
21	Ground
22	Pulse output 2
21	Ground

6.14 Security system

The E230 meter has four (ZxR100xC) or five (ZMR100xR) authentication levels. Level 0 does not require any password, level 1 has an uncoded password, level 2 a coded password, level 3 a coded password plus requires physical hardware interaction of the MD button press (ZMR100xR only) and level 4 requires both an internal hardware switches and a password (factory only).

Level 0 provides read access to all data, level 1 write access to non-critical data and level 2 write access to non-critical parameters.




Figure 21. E230 ZxR100xC security levels




Figure 22. E230 ZMR100xR security levels

6.14.1 Access level 3 (ZMR100xR only)

Level 3 access can be utilised if: (a) level 3 is enabled in the configuration, (b) “Auto Restart” display option is set and (c) the meter is fitted with the orange MD button.

First, press the display button to obtain all display segments (‘display test’) and then press the MD button (MD seal must be removed).

Note: The duration of press for both buttons is not of any significance here as long as they are pressed in the correct sequence (MD reset button press after pressing display button at all segments on).

The sequence of button presses should be done after the sign on for obtaining the level 3 access. Flag read/write signing on to the meter at P0 access will allow all P3 access permissions to be parameterised.

6.14.2 Last configuration change identifier

A special register C.128.0 is defined (for the use of a 3rd party) to read and write an identifier relating to the user who made the last change to the configuration of the meter. 8 bytes (suitable for 8 alphanumeric characters) are permitted at address 0x269F. Subject to the setting of the security parameter “LastChangeldent”, register C.128.0 can be enabled for viewing in the IEC readout or left for reading directly by formatted command. The adjacent address 0x0BFA will contain the date and time stamp in the format: yy-mm-dd; hh:mm.

6.15 IEC formatted commands

Available commands are (but not limited to):

- Perform IEC data readout
- Read and set ID1s and ID2s
- Read parameterisation ID
- Read and set IEC device address
- Read and set optical interface baud rate
- Read and set electrical interface baud rate
- Read and set pulse output settings
- Read and set LCD Recall List
- Read and set LCD Service List
- Read and set Readout List
- Read and set No Power Display List
- Set rate switching
- Set passwords
- Set register resolution
- Reset Billing/MD period
- Enable/Disable test mode
- Reset Energy and Demand registers
- Reset Error register
- Reset Tamper Flags
- Reset Fraud Detection

- Reset Magnetic Fraud Detection
- Reset Terminal Cover Fraud Detection
- Reset Meter Cover Fraud Detection

ZxR100xC only

- Read and set EDL21 registers
- Reset EDL specific registers

ZMR100xR only

- Read and set date/time and DST
- Perform Load Profile readout
- Perform Event log readout
- Read last parameterisation change ID
- Read and set Time of Use (TOU)
- Read and set Billing (Stored Values) settings and parameters
- Reset Alert indicator
- Reset Billing period counter
- Reset Operating Time registers
- Reset Billing (Stored Values)
- Reset Load Profile

7 Maintenance

7.1 Meter check

While it is not necessary, under normal circumstances, to perform any maintenance on the installed meter, the following are check points that should be observed during scheduled periodic meter visits.

- Is the meter dry and clean, particularly the LCD display and the optical interface?
- Does the meter display a legible and sensible display? I.e. does the meter appear to be in a serviceable condition?
- Check that all factory- and company-fitted seals are secure and intact.
- Observe display for any error messages or notifications
- Confirm that the energy registers have changed to a reasonable degree since the last visit.
- If irregularities are found, continue as described in section 7.3.

7.2 Meter testing

The testing of meters, either random sample or on all meters, should be carried out periodically according to national regulations. The meter must be removed as described in section 7.4 and replaced with a meter of similar type for the duration of the tests.

7.2.1 Measurement Times

For technical reasons, higher measurement deviations can occur during short-term measurements. It is therefore recommended to use sufficiently long measurement times in order to achieve the required accuracy.

Table of required measurement times:

ZMR

$U_n=230V$

	Measurement Uncertainty 0.2%			Measurement Uncertainty 0.1%		
	3 ph	1 ph	3 ph	3 ph	1 ph	3 ph
Current [A]	$\cos\varphi=1$	$\cos\varphi=1$	$\cos\varphi=0.5$	$\cos\varphi=1$	$\cos\varphi=1$	$\cos\varphi=0.5$
0.2	25 s	70 s	90 s	90 s	4.5 min	6 min
0.5	20 s	20 s	20 s	20 s	45 s	60 s
≥ 1	20 s	20 s	20 s	20 s	20 s	20 s

3 ph = balanced load 1 ph = single-phase load

ZFRU_n=230V

	Measurement Uncertainty 0.2%			Measurement Uncertainty 0.1%		
	3 ph	1 ph	3 ph	3 ph	1 ph	3 ph
Current [A]	cosφ=1	cosφ=1	cosφ=0.5	cosφ=1	cosφ=1	cosφ=0.5
0.2	45 s	3 min	3 min	3 min	12 min	11 min
0.5	20 s	30 s	27 s	30 s	2 min	2 min
≥ 1	20 s	20 s	20 s	20 s	30 s	30 s
≥ 2	20 s	20 s	20 s	20 s	20 s	20 s

3 ph = balanced load 1 ph = single-phase load

For meters with software ≤K75 or ≤K52:

If the so-called register test (meter constant or gear transmission error test) is not carried out at a constant load point, but with a constant injected amount of energy, a test time of 15 minutes is recommended (minimum 10 minutes).

7.2.2 Post-installation configuration changes

With the aid of a laptop computer or a suitable PDA together with a flag probe and Landis+Gyr-specific software, it is possible to amend some of the factory configured options of the meter. However, it is beyond the scope of this manual to describe the procedure in any further detail. Landis+Gyr Metering sales team would be happy to discuss specific requirements, if they arise.

7.3 Operating faults

If the LCD window is illegible or the data readout does not function, the following points should be checked.

- Is mains voltage present?
- Are the preliminary fuses intact?
- Has the minimum or maximum recommended ambient temperature been exceeded?
- Is the LCD window clear of all debris? – Not misted over, painted over or soiled in any way.

If none of the above are causing the fault, the meter should be disconnected as described in section 7.4, replaced if required as detailed in section 5, and returned to Landis+Gyr as described in section 7.5.

7.4 Disconnecting the meter



Remove preliminary fuses before continuing

The connecting conductors should not be live when removing the meter. Electrically live parts are a life threatening hazard. Preliminary fuses should be removed and kept in a safe place, where they cannot be replaced by anyone unnoticed, until all work is complete.

Proceed as follows:

1. Remove the company seal on the terminal cover (if fitted).
2. Release the two terminal cover screws and remove terminal cover.
3. Check with a suitable voltage testing device that the phase connections are not live. If they are live, remove the preliminary fuses and keep in a safe place, where they cannot be replaced by anyone unnoticed, until all work is complete.
4. Remove the signal inputs and outputs by releasing the auxiliary terminal screws.
5. Remove the phase connections by releasing the main terminal screws.
6. If required, fit a suitable replacement meter as described in section 5.

7.5 Repairing the meter

There are no user serviceable parts inside the meter. Breaking factory calibration seals will invalidate the calibration status of the meter. In the event of a meter requiring repair, proceed as follows.

1. Remove the meter from the installation as detailed in section 7.4.
2. Attach a label, which describes the fault as accurately as possible, to the meter and include the name and contact details of the person responsible in case of inquiries.
3. Package the meter to ensure no further damage can occur during transit.
4. Send the meter back to Landis+Gyr.

8 Error handling

8.1 Error codes

This error display is added to the end of the current display, if it is not already parameterised to display in the main display sequence.

On the display of E230 meters, an error is shown as an eight digit hexadecimal value, i.e. the single digits may show values between 0 (no error code set) and F (all four error codes set). The index field shows "F.F.0".

There are two kinds of errors: persistent and transient errors. Transient error codes are automatically reset at the next readout. The errors can also be cleared either using the formatted write command "Reset Error Register" (W2 C150) command in .MAP110 tool or by power cycling the meter.



Note

The formatted write command "Reset Error Register" (W2 C150) command using .MAP110 only clears the error flags, it does not eliminate the error.

Persistent error codes cannot be reset in the field. If the reason for the error persists, for example in the case of a component failure, power cycling will not clear the error. A meter showing a persistent error code must be considered unsafe/unsuitable for further use. Contact a Landis+Gyr Service Centre for support.

If more than one error is detected, the error codes are added. If e.g. the two errors "00002000" and "00008000" occur simultaneously, the error code would be the sum of these error codes = "0000A000" (note that the error code is a hex value).

The error message in the readout does not correspond to the displayed error. The value of this error is bitmapped:

Display	Description	If error is persistent	If error is transitional	Related event log #
80000000	RTC has drifted too far. This error only gets set, if using MLC option is enabled.	Billing based on energy registers after the error occurrence is not reliable and may be subject to discrepancies and incorrect time-based tariff switching.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110, power-cycle or wait for the error to be cleared automatically after RTC correction. It gets cleared at 03:20:30 hours.	N/A

Display	Description	If error is persistent	If error is transitional	Related event log #
40000000	<i>UNUSED</i>			
20000000	<i>UNUSED</i>			
10000000	<i>UNUSED</i>			
08000000	<i>UNUSED</i>			
04000000	<i>UNUSED</i>			
02000000	Battery power reserve exhausted.	Meter may not operate under NPR conditions. RTC may become incorrect or reset when mains supply is removed. If the supercapacitor option is fitted, it will support the RTC for a limited time without battery.	Cleared by leaving on mains power for a minimum of 3 days or by power-cycle, since battery health is checked during the power-up sequence.	N/A
01000000	<i>UNUSED</i>			
00800000	Error saving energy registers.	Energy registers may be missing up to 60 minutes worth of energy consumption per power-down.	A retry after 60 minutes is made from RAM to EEPROM in order to save the energy registration. If successful, the meter will show correct energy consumption. Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A
00400000	Error restoring energy registers. (Unable to read from EEPROM.)	Meter operation may be compromised. Billing based on energy registers after the error occurrence is not reliable. This error will only occur during the power-up sequence.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A

Display	Description	If error is persistent	If error is transitional	Related event log #
00200000	Error Reading/ Writing tamper microcontroller.	Tamper functionality in NPR mode may be affected. Meter operations are not compromised, i.e. only tampers that occurred in NPR mode may not be recorded and logged by the meter.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110, power-cycle or wait for the error to be cleared automatically once communication is re-established.	N/A
00100000	<i>UNUSED</i>			
00080000	RTC Error. (TOU meters only).	Billing based on energy registers after the error occurrence is not reliable and may be subject to discrepancies and incorrect time-based tariff switching. Billing Profile (stored values) will not be created following this event type and therefore Load Profile data may also be compromised. Maximum Demand will be calculated at configured intervals. Caused by the meter's inability to read/write to RTC.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or wait for the error to be cleared automatically after RTC correction.	76

Display	Description	If error is persistent	If error is transitional	Related event log #
00040000	Date Time invalid (TOU meters only).	Billing based on energy registers after the error occurrence is not reliable and may be subject to discrepancies and incorrect time-based tariff switching. Billing Profile (stored values) will not be created following this event type and therefore Load Profile data may also be compromised. Maximum Demand functions independently of this error type and is not affected. Battery Operating Time functionality will no longer be reliable once this error bit is set.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or wait for the error to be cleared automatically after RTC correction.	66
00020000	Error accessing EEPROM.	Meter operation may be compromised. Billing based on energy registers after the error occurrence is not reliable.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A
00010000	<i>UNUSED</i>			
00008000	Failed checksum when restoring registers from EEPROM. (No backup of registers available.)	Meter operation may be compromised. Billing based on energy registers after the error occurrence is not reliable. Error will only occur during the power-up sequence.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A

Display	Description	If error is persistent	If error is transitional	Related event log #
00004000	Power-fail data failed checksum.	Meter operation may be compromised. Billing based on energy registers after the error occurrence is not reliable. Error will only occur during the power-up sequence. This error is set, if the checksum of the power-fail data is incorrect during power-up.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A
00002000	Calibration value failed checksum.	Meter operation may be compromised. Billing based on energy registers after the error occurrence is not reliable. Error will only occur during the power-up sequence. This error is set, if the checksum of the calibration data is incorrect during power-up.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A
00001000	<i>UNUSED</i>			
00000800	<i>UNUSED</i>			
00000400	<i>UNUSED</i>			
00000200	<i>UNUSED</i>			
00000100	<i>UNUSED</i>			
00000008	Error in Parameter Data.	Meter operation may be compromised due to incorrect or corrupt parameterisation.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	N/A
00000040	<i>UNUSED</i>			

Display	Description	If error is persistent	If error is transitional	Related event log #
00000002	More than 32 consecutive attempts to communicate with or initialise the MMI devices have failed.	Energy measurement is compromised. Communication with measurement device(s) has failed and some or all energy is not measured.	Only by power-cycle.	N/A
00000010	<i>UNUSED</i>			
00000004	<i>UNUSED</i>			
00000001	Insufficient time to complete power failure routine.	Energy registers may be missing up to 60 minutes worth of energy consumption and power-fail data per power-down.	Clear Error Register F.F.0 on display and readout by "Reset Error Register" (W2 C150) command using .MAP110 or by power-cycle.	89

8.2 Formatted commands and error codes

If a formatted command is not properly executed, one of the following error codes is sent in response to any R1/R2/W1/W2/E2 command:

- **ER20:** If the user does not have read or write permissions to that section.
- **ER23:** If an unsupported command is sent to the meter.
- **ER26:** If there is an error in reading from or writing to EEPROM.
- **ER30:** If the user has read or write permissions, but command data is not valid (e.g. the IEC device address must be numeric only: if the user tries to write 999A0999 in the address, the response will be ER30).

If none of the above cases are true and there are still problems with communication, "NAK" (not acknowledged) is sent in response.

9 Decommissioning and disposal



The procedure for the safe removal of the meter from the installation is described in 7.4. Please ensure that **ALL SAFETY PRECAUTIONS** are met before proceeding.

The components used to manufacture the device can, in the main, be broken down into constituent parts and sent to an appropriate recycling or disposal facility. When the product is removed from use, the whole product must be sent to a professional electronic waste treatment process. The waste treatment and disposal plants must be approved by local regulatory authorities.

The end processing of the product and recycling of its components must always be carried out in accordance with the rules and regulations of the country where the end processing and recycling are done.

On request, Landis+Gyr will provide more information about the environmental impact of the product.



This product must not be disposed of in regular waste. Use a professional electronic waste treatment process.



The following are general guidelines and should NOT take precedence over local environmental laws and policies, which should be adhered to without compromise.

Component parts	Disposal
Printed circuit boards	Delivered to recycling plants
Metal components	Sorted and delivered to metal recycling plants
Plastic components	Sorted and delivered to re-granulation if at all possible
Batteries	Removed from meter and delivered to specialised recycling plants

10 Terms and abbreviations

10.1 Acronyms

The following terms and abbreviations are used in this document.

Term	Description
BS	British Standard
DFS	Direct Field Sensor
DIN	Deutsches Institut für Normung (German Institute for Standardisation)
ECD	External Connection Diagram
EEPROM	Electrically Erasable Programmable Read Only Memory (E2)
IEC	International Electrotechnical Commission
ISO	International Standards Organisation
LCD	Liquid Crystal Display
LED	Light Emitting Diode
MD	Maximum Demand
MID	Metering Industry Directive
NPR	No Power Read
OFGEM	The Office of Gas and Electricity Markets
PTR	Photo-transistor
RED	Reverse Energy Detected

10.2 Units

Unit	Description
A	Ampere (unit of current)
Hz	Hertz (unit of frequency)
I_{ref}	MID reference current
Kg	Kilogramme (unit of weight)
kVAh	Kilo Volt Ampere hour
kVArh	kilo Volt Amps reactive hour
kWh	kilo Watt-hour
mm	millimetre (unit of distance)
m Ω	milliohm (unit of resistance)
ms	millisecond
Nm	Newton meter (unit of torque)
°C	Degree Celsius (unit of temperature)
UN	Rated supply voltage of meter
UT	Rated external switch voltage
V	Volt

10.3 Standards

Standard	Brief definition
BS 1361	Specification for fuse links
DIN 43857	Specification for meter design details (dimensions, etc.)
IEC 1107	Optical Interface standard, now known as IEC 62056-21:2002
IEC 61000-4-2	Electrostatic discharge immunity tests
IEC 61000-4-3	Radiated, radio-frequency, electromagnetic field immunity test
IEC 61000-4-4	Electrical fast transient/burst immunity test
IEC 61107 / DIN 66258	See IEC 1107
IEC 947-1	Standard for low voltage switchgear and control gear
IEC 947-3	Standard for low voltage switchgear and control gear
IEC/CISPR 22	Radio interference suppression limits
ISO 14001	Environmental Management Standard
MID	Measuring Instruments Directive, directive 2004/22/EC of the European Parliament and of The Council
IEC 62052-11	Electricity metering equipment (a.c.) - General requirements, tests and test conditions - Part 11: Metering equipment
IEC 62053-21	Electricity metering equipment (a.c.) - Particular requirements - Part 21: Static meters for active energy (classes 1 and 2)
IEC 62053-23	Electricity metering equipment (a.c.) - Particular requirements - Part 23: Static meters for reactive energy (classes 2 and 3)
IEC 62053-31	Electricity metering equipment (a.c.) - Particular requirements - Part 31: Pulse output devices for electromechanical and electronic meters (two wires only)
EN 50470-1	Electricity metering equipment (a.c.). General requirements, tests and test conditions. Metering equipment (class indexes A, B and C)
EN 50470-3	Electricity metering equipment (a.c.). Particular requirements. Static meters for active energy (class indexes A, B and C)

Contact:

Landis+Gyr AG
Theilerstrasse 1
CH-6301 Zug
Switzerland
Phone: +41 41 935 6000
www.landisgyr.com

Landis
|Gyr+
manage energy better