



96x96

SPECIFICATIONS

DISPLAY

Liquid crystal display with backlight
4 lines, 4 digits per line to show electrical Parameters
5th line, 8 digits to show energy
Bar graph for current indication as percentage of CT rating

LCD INDICATIONS

- I** - Integration of energy
- PRG** - Unit is in configuration menu
- - Communication in progress
- MAX DMD** - Maximum & Minimum Demand of Power

WIRING INPUT

3 Ø - 4 wire

RATED INPUT VOLTAGE

100 to 240V AC (L-N) ; 173 to 415V AC (L-L)

FREQUENCY RANGE

45-65 Hz

CT PRIMARY

5A to 10,000A (Programmable for any Value)

CT SECONDARY

330mV

PT PRIMARY

100V to 500kV (Programmable for any value)

PT SECONDARY

100 to 500V AC (L-L)(Programmable for any value)

Display update time

1 sec for all parameters

Display Scrolling

Automatic / Manual

AUXILIARY

Self supplied

TEMPERATURE

Operating : 0 to 50°C
Storage : -20 to 75°C

HUMIDITY

85% non-condensing

MOUNTING

Panel mounting

WEIGHT

230gms

OUTPUT

Pulse Output : Voltage range : External 24V DC max.
Current capacity : 100 mA max

Pulse Width : Selectable between 50ms to 250ms

SERIAL COMMUNICATION

Interface standard & protocol	RS485 & MODBUS RTU
Communication address	1 to 255
Transmission mode	Half duplex
Data types	Float and Integer
Transmission distance	500 Metre maximum
Transmission speed	300, 600, 1200, 2400, 4800, 9600, 19200 (in bps)
Parity	None, Odd, Even
Stop bits	1 or 2
Response time	100 ms (max and independent of baud rate)

PULSE VALUE

CT Rating	kWh
160A	0.1K
250A	0.1K
400A	0.1K
800A	1K

NOTE : 1) For Voltage, Current, Power, resolution is automatically adjusted.
2) For power factor, resolution is 0.001
3) INT blinks after every 5 seconds, if load is connected on at least any one of 3 phases.

ACCURACY

Measurement	Accuracy
Voltage V_{L-N}	±0.5% of Full scale
Voltage V_{L-L}	±0.5% of Full scale
Current	±0.5% of Full scale
Frequency	±0.1% For L-N Voltage >20V , For L-L Voltage >35V
Active Power	1%
Apparent power	1%
Reactive Power	1%
Power factor	±0.01
Active energy	1%
Reactive energy	1%
Apparent energy	1%
MAX / MIN Active Power	1%
MAX / MIN Reactive Power	1%
MAX Apparent Power	1%

SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

CAUTION

Read complete instructions prior to installation and operation of the unit.

CAUTION : Risk of electric shock.

WIRING GUIDELINES

WARNING:

- To prevent the risk of electric shock, power supply to the equipment must be kept OFF whilst installing the wiring .
- Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
- Cable used for connection to power source, must have a cross section of 1.5mm². These wires shall have current carrying capacity of 6A.
- Before attempting work on device, ensure absence of voltages using appropriate voltage detection device.

MAINTENANCE

- The equipment should be cleaned regularly to avoid blockage of ventilating parts.
- Clean the equipment with a clean soft cloth.
Do not use Isopropyl alcohol or any other cleaning agent.

INSTALLATION GUIDELINES

CAUTION:

- This equipment, being of a built-in-type, normally becomes a part of a main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- Conductors must not come in contact with the internal circuitry of the equipment or it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
- Protection & disconnection means must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function & must be installed in a convenient position normally accessible to the operator.


CAUTION :

The equipment shall not be installed in environmental conditions other than those mentioned in this manual.

MECHANICAL INSTALLATION

For installing the meter

- Prepare the panel cutout with dimensions as shown below :



- Push the meter into the panel cutout. Secure the meter in its place by fitting the clamp from the rear side. Fit clamps on both sides in diagonally opposite location for optimum fitting.
- For proper sealing, tighten the screws evenly with required torque.
- Recommended conductor cross section = 1.5mm²
Screw clamp tightening torque = 0.1N-m


CAUTION:

The equipment in its installed state must not come in close proximity to any heating sources, caustic vapors, oil, steam, or other unwanted process by-products.

EMC Guidelines:

- Use input power cables with shortest connections.
- Layout of connecting cables shall be away from any internal EMI source.

TERMINAL CONNECTIONS



MODBUS REGISTER ADDRESSES LIST

MODBUS register addresses list					
Readable Parameters For MRJ385					
Address	Hex Address	Parameter	Length (Register)	Data Structure	
30000	0x00	Voltage V1N	2	Float	
30002	0x02	Voltage V2N	2	Float	
30004	0x04	Voltage V3N	2	Float	
30006	0x06	Average Voltage LN	2	Float	
30008	0x08	Voltage V12	2	Float	
30010	0x0A	Voltage V23	2	Float	
30012	0x0C	Voltage V31	2	Float	
30014	0x0E	Average Voltage LL	2	Float	
30016	0x10	Current I1	2	Float	
30018	0x12	Current I2	2	Float	
30020	0x14	Current I3	2	Float	
30022	0x16	Average Current	2	Float	
30024	0x18	kW1	2	Float	
30026	0x1A	kW2	2	Float	
30028	0x1C	kW3	2	Float	
30030	0x1E	kVA1	2	Float	
30032	0x20	kVA2	2	Float	
30034	0x22	kVA3	2	Float	
30036	0x24	kVAr1	2	Float	
30038	0x26	kVAr2	2	Float	
30040	0x28	kVAr3	2	Float	
30042	0x2A	Total KW	2	Float	
30044	0x2C	Total KVA	2	Float	
30046	0x2E	Total KVAr	2	Float	
30048	0x30	PF1	2	Float	
30050	0x32	PF2	2	Float	
30052	0x34	PF3	2	Float	
30054	0x36	Average PF	2	Float	
30056	0x38	Frequency	2	Float	
30058	0x3A	kWh	2	Float	
30060	0x3C	kVAh	2	Float	
30062	0x3E	kVArh	2	Float	
30064	0x40	kW Max Active Power	2	Float	
30066	0x42	kW Min Active Power	2	Float	
30068	0x44	kVAr Max Reactive Power	2	Float	
30070	0x46	kVAr Min Reactive Power	2	Float	
30072	0x48	kVA Max Apparent Power	2	Float	
30074	0x4A	MAX I1 Demand	2	Float	
30076	0x4C	MAX I2 Demand	2	Float	
30078	0x4E	MAX I3 Demand	2	Float	
30080	0x50	MAX Avg Demand	2	Float	
30082	0x52	Run hour	2	Float	
30084	0x54	kWh1 (Imp)	2	Float	
30086	0x56	kWh2 (Imp)	2	Float	
30088	0x58	kWh3 (Imp)	2	Float	
30090	0x5A	kWh1 (Exp)	2	Float	
30092	0x5C	kWh2 (Exp)	2	Float	
30094	0x5E	kWh3 (Exp)	2	Float	
30096	0x60	Total kWh (Imp)	2	Float	
30098	0x62	Total kWh (Exp)	2	Float	
30100	0x64	kVArh1 (Imp)	2	Float	
30102	0x66	kVArh2 (Imp)	2	Float	
30104	0x68	kVArh3 (Imp)	2	Float	
30106	0x6A	kVArh1 (Exp)	2	Float	
30108	0x6C	kVArh2 (Exp)	2	Float	
30110	0x6E	kVArh3 (Exp)	2	Float	
30112	0x70	Total kVArh (Imp)	2	Float	
30114	0x72	Total kVArh (Exp)	2	Float	
30116	0x74	kVAh1	2	Float	
30118	0x76	kVAh2	2	Float	
30120	0x78	kVAh3	2	Float	

Readable / writable parameters :						
Address	Hex Address	Parameter	Range		Length (Register)	Data Structure
			Min value	Max value		
40000	0x00	Password	0	9998	1	Integer

MODBUS register addresses list <i>continued</i>						
Readable / writable parameters from MRJ385 :						
Address	Hex Address	Parameter	Range		Length (Register)	Data Structure
			Value	Meaning		
40001	0x01	N/W Selection (Readable Only)	0	3P-4W	1	Integer
			1	3P-3W	1	Integer
40002	0x02	CT Secondary (Readable Only)	1			
			5			
40003	0x03	CT primary (CT Secondary = 5)	5	10000	1	Integer
			1	10000		
40004	0x04	PT Secondary	100	500	1	Integer
			100	500KV	2	Integer
40005	0x05	PT primary	Value	Meaning		
			1	255	1	Integer
40007	0x07	Slave id	0x0000	300	1	Integer
			0x0001	600		
40008	0x08	Baud rate	0x0002	1200		
			0x0003	2400		
40009	0x09	Parity	0x0004	4800		
			0x0005	9600		
40010	0x0A	Stop bit	0x0006	19200		
			0x0000	None	1	Integer
40011	0x0B	Backlight OFF	0x0001	Odd		
			0x0002	Even		
40012	0x0C	Factory Default	0x0000	1	1	Integer
			0x0001	2		
40016	0x10	Auto Mode Pages	Min Value : 1	Max Value : 8		
			Page No	Meaning		
40017	0x11	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40018	0x12	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40019	0x13	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40020	0x14	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40021	0x15	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40022	0x16	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40023	0x17	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40024	0x18	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40025	0x19	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40026	0x1A	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40027	0x1B	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40028	0x1C	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40029	0x1D	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40030	0x1E	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40031	0x1F	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40032	0x20	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40033	0x21	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40034	0x22	Demand Interval Method	Value	Meaning		
			0X0000	Sliding	1	Integer
40035	0x23	Demand Interval Duration	0X0001	Fixed		
			MIN Value : 1	MAX Value : 30	1	Integer
40036	0x24	Demand Interval Length	MIN Value : 1	MAX Value : 30	1	Integer
40042	0x2A	Page Address Sequence	1-18	1-First Page; 18-Last Page	1	Integer
40043	0x2B	Reset Max	1	Reset all Max power	1	Integer
40044	0x2C	Reset Energy	1	Reset all energy to factory setting range	1	Integer
40045	0x2D	Reset Run Hour	1	Reset Run hour	1	Integer

FRONT PANEL DESCRIPTION



ONLINE PAGE DESCRIPTION

There are 6 dedicated keys labelled as V, I, VAF, PF, P, E. Use these 6 keys to read meter parameters. Simply press these keys to read the parameters.

KEY PRESS	ONLINE PAGE DESCRIPTION
Press "V"	<p>The first screen: Displays Line to Neutral Voltage of three phases & average Line to Neutral Voltage.</p> <p>The second screen: Displays Line to Line Voltage of three phases & average line to line Voltage.</p>
Press "I"	<p>The first screen : Displays phase Current of three phases & average phase Current.</p> <p>The second screen : Displays the maximum current demand.</p>
Press "VAF"	<p>The first screen: Displays Voltage, Current, Power factor of first phase & Frequency.</p> <p>The second Screen: Displays Voltage, Current, Power factor of second phase & Frequency.</p> <p>The third Screen: Displays Voltage, Current, Power factor of third phase & frequency.</p> <p>The fourth Screen: Displays Average, Value of Voltage, Current, Power factor of three phases & Frequency.</p>
Press "PF"	<p>The first screen: Displays Power factor of three phases & average Power factor.</p>

KEY PRESS	ONLINE PAGE DESCRIPTION
Press "P"	<p>The first screen : Displays Active power of three phases & total Active Power.</p> <p>The second screen: Displays Reactive Power of three phases & total Reactive Power.</p> <p>The third screen : Displays Apparent Power of three phases & total Apparent Power.</p> <p>The fourth screen : Displays Active, Reactive , Apparent power & Power factor of first phase.</p> <p>The fifth screen : Displays Active, Reactive, Apparent power & Power factor of second phase.</p> <p>The sixth screen : Displays Active, Reactive, Apparent power & Power factor of third phase.</p> <p>The seventh screen : Displays total Active, Reactive , Apparent power & average Power factor of three phases.</p> <p>The eighth screen : Displays maximum Active power demand, Reactive power demand & Apparent power demand.</p> <p>The ninth screen : Displays minimum Active power demand & Reactive power demand.</p>
Press "E"	<p>The first screen : Displays phasewise Active energy of three phases.</p> <p>The second screen : Displays phasewise Reactive energy of three phases.</p> <p>The third screen : Displays phasewise Apparent energy of three phases.</p> <p>The fourth screen : Displays total Run hour</p>

AUTOMATIC / MANUAL MODE DESCRIPTION

Press E (←) button for 3 seconds to toggle between Automatic & Manual mode.

Note: By default unit operates in automatic mode. In automatic mode online pages scroll automatically at the rate of 5 seconds per page. In automatic mode when any key is pressed, unit temporarily switches to manual mode and the appropriate page is displayed, also if no key is pressed for 5 sec, unit resumes automatic mode.

CONFIGURATION

There are 6 dedicated keys with symbols marked as ◀, ▶, ▲, ▼, ←, → use these 6 keys to enter into configuration menu / change setting.

Note : The settings should be done by a professional, after going through this users manual and after having understood the application situation. For the configuration setting mode :


- Use ▲ + ▼ keys for 3 sec to enter or exit from the configuration menu.
- Use ◀ or ▶ keys to move cursor left or right by one digit each time.
- Use ▲ or ▼ keys for increasing or decreasing parameters value.
- Use ← key to go back to previous page.
- Use → key to save the setting and move on to next page.

Config page.	Function	Range or Selection	Factory Setting
	Password	0000 to 9998	1000
1	Change Password	No / Yes	No
1.1	New Password	0000 to 9998	1000
2	Network Selection	Preset	3P4W
3	CT Secondary	Preset	5
4	CT Primary	5A to 10,000A (10.0kA)	160
5	PT Secondary	100V to 500V	350
6	PT primary	100V to 500kV	350
7	Slave Id	1 to 255	1
8	Baud Rate	300, 600,1200, 2400, 4800, 9600 & 19200	9600
9	Parity	None, Even, Odd	None
10	Stop Bit	1 or 2	1
11	Back Light	0 to 7200 sec.	0000
12	Demand interval method	Sliding / Fixed	Sliding
13	Demand interval duration	1 to 30	15
14	Demand interval length	1 to 30 min	1
15	Max Page Auto	1 to 18	18
16	Change Page Sequence	No / Yes	No
16.01	Page sequence 1	_____	1
16.02	Page sequence 2	_____	2
16.03	Page sequence 3	_____	3
16.04	Page sequence 4	_____	4
16.05	Page sequence 5	_____	5
16.06	Page sequence 6	_____	6
16.07	Page sequence 7	_____	7
16.08	Page sequence 8	_____	8
16.09	Page sequence 9	_____	9
16.10	Page sequence 10	_____	10
16.11	Page sequence 11	_____	11
16.12	Page sequence 12	_____	12
16.13	Page sequence 13	_____	13
16.14	Page sequence 14	_____	14
16.15	Page sequence 15	_____	15
16.16	Page sequence 16	_____	16
16.17	Page sequence 17	_____	17
16.18	Page sequence 18	_____	18
17	Pulse duration	50, 100, 150, 200 & 250	200
18	Factory Default	No / Yes	NO
19	Reset Energy & Max Demand	No / Yes	NO
•19.1	Password	0001 To 9999	1001
19.01	Reset Active Energy	No / Yes	NO
19.02	Reset Reactive Energy	No / Yes	NO
19.03	Reset Apparent Energy	No / Yes	NO
19.04	Reset Max Power	No / Yes	NO
19.05	Reset Run Hour	No / Yes	NO

• For resetting energy parameters user will be prompted for password. If correct password is entered, the user will be able to reset all energy parameters. This password will be value which will be greater than the configuration password by 1.

APPLICATION OF PULSE OUTPUT

• PROCESS INTEGRATION



Pulse output from MRJ385 meter can be interfaced into a process through a PLC for on line control of energy content in the process. If the PLC has a self excited 24V digital input, external 24V DC supply is not needed. The kWh pulse is also used to derive average kWh information at the PLC.

LEFT HAND CT MOUNTING PHASE CORRECTION

The meter phases L1, L2 & L3 are setup as default for the CT to be mounted as an incomer or on the RH side of the board.

Meter display shows rH when "I" is pressed for 3 seconds.

When the CT is mounted on the LH side of the board the phase sequence needs to be reversed.

- Press "I" for seconds, then release and then press again for 3 seconds. Phase will be reversed and display will show LH
- Wait 5 seconds for meter to resume online reading. Meter display shows LH when "I" is pressed for 3 seconds.

Meter/CT Ratio Setup -

the meter default CT setting is 160A. to set the meter to other CT sizes follow instructions below.

- Press ▼ & ▲ keys together for 3 seconds to enter configuration menu.
- To enter default password 1000 - Press ◀ then press ▲. Press ← 4 times to move on and to enter CT primary page 04.
- Press ◀ or ▶ to select the digit to change and press ▲ or ▼ to raise or lower the CT value. Set to 250,400or 800 to match CT.
- Press → to save settings and move on.
- Press ▼ & ▲ keys together for 3 seconds to exit configuration menu.

Specifications subject to change as development is a continuous process.

Selec Controls Pvt. Ltd., India

Tel:91-22-28476443/1882, Fax:91-22-28471733,
Toll free: 1800 227 353, Website: www.selec.com
E- mail: sales@selec.com.